

INVERTER WALL MOUNTED TYPE RESIDENTIAL AIR-CONDITIONERS

(Split system, air to air heat pump type)

SRK20ZS-W, -WB, -WT

25ZS-W, -WB, -WT

35ZS-W, -WB, -WT


50ZS-W, -WB, -WT

CONTENTS

1.	SPE	CIFICATIONS	3
2.	EXT	ERIOR DIMENSIONS	16
	(1)	Indoor units	16
	(2)	Outdoor units	17
	(3)	Remote control	19
3.	ELE	CTRICAL WIRING	22
	(1)	Indoor units	22
	(2)	Outdoor units	23
4.	NOI	SE LEVEL	25
5.	PIPI	NG SYSTEM	43
6.	RAN	IGE OF USAGE & LIMITATIONS	45
7.	CAP	PACITY TABLES	47
8.	APP	LICATION DATA	48
	(1)	Installation of indoor unit	48
	(2)	Installation of outdoor unit	56
	(3)	Safety precautions in handling air-conditioners with flammable refrigerants	60
9.	OUT	LINE OF OPERATION CONTROL BY MICROCOMPUTER	62
	(1)	Operation control function by wireless remote control	62
	(2)	Unit ON/OFF button	63
	(3)	Auto restart function	63
	(4)	Installing two air-conditioners in the same room	63
	(5)	Selection of the annual cooling function	64
	(6)	Heating only function	64
	(7)	High power operation	64
	(8)	Economy operation	65
	(9)	Air flow direction adjustment	65
	(10)	3D auto operation	66
	(11)	Timer operation	67
	(12)	Silent operation	67
	(13)	Night setback operation	67
	(14)	Air flow range setting	
	(15)	Display brightness adjustment	68
	(16)	Outline of heating operation	69
	(17)	Outline of cooling operation	
	(18)	Outline of dehumidifying (DRY) opertaion	71
	(19)	Outline of automatic operation	71

	(20)	Protective control function	72
10.	MA	NTENANCE DATA	79
	(1)	Cautions	79
	(2)	Items to check before troubleshooting	79
	(3)	Troubleshooting procedure (If the air-conditioner does not run at all)	79
	(4)	Troubleshooting procedure (If the air-conditioner runs)	80
	(5)	Self-diagnosis table	81
	(6)	Service mode (Trouble mode access function)	82
	(7)	Inspection procedures corresponding to detail of trouble	90
	(8)	Phenomenon observed after short-circuit, wire breakage on sensor	95
	(9)	Checking the indoor electrical equipment	95
	(10)	How to make sure of wireless remote control	97
	(11)	Inspection procedure for blown fuse on the indoor and outdoor PCB	97
	(12)	Outdoor unit inspection points	98
11.	OP	TION PARTS1	101
	(1)	Wired remote control	101
	(2)	Interface kit (SC-BIKN2-E)	117
	(3)	Superlink E board (SC-ADNA-E)	121
12	TE	CHNICAL INFORMATION	122

■How to read the model name



1. SPECIFICATIONS

			Model	SRK2	0ZS-W	
Item				Indoor unit SRK20ZS-W	Outdoor unit SRC20ZS-W	
Power source	De .			1 Phase, 220 - 240\	/, 50Hz / 220V, 60Hz	
	Nominal cooling capacity (rar	nge)	kW	2.0 (0.9 (Min	.) - 2.9 (Max.))	
	Nominal heating capacity (range)		kW	2.7 (0.9 (Min.) - 4.3 (Max.))		
	Heating capacity (H2)		kW	_		
		Cooling		0.44 (0.1	9 - 0.80)	
	Power consumption	Heating	kW	0.59 (0.2	20 - 1.40)	
		Heating (H2)	1	-		
	Max power consumption	1 3 ()		1.	65	
		Cooling		2.6 / 2.5 / 2.4 (220/ 230/ 240V)	
	Running current	Heating	A		220/ 230/ 240V)	
Operation	Inrush current, max current		1	3.2 / 3.0 / 2.9 (220/	230/ 240V) Max. 9	
data		Cooling			79	
	Power factor	Heating	- %	3	35	
	EER	Cooling		4.	55	
		Heating	1		58	
	COP	Heating (H2)	1		- -	
		Cooling		48	56	
	Sound power level	Heating	1	50	56	
		Cooling	dB(A)	Hi: 34 Me: 25 Lo: 22 ULo: 19	45	
	Sound pressure level	Heating	()	Hi: 36 Me: 29 Lo: 23 ULo: 19	45	
	Silent mode sound pressure level		1	——————————————————————————————————————	Cooling:42 / Heating:43	
Exterior dim	ensions (Height x Width x Dept		mm	290 x 870 x 230	540 x 780(+62) x 290	
Exterior app		•••	1	Fine snow (Pure white)	Stucco white	
(Equivalent color : Munsell, RAL)				(8.0Y 9.3/0.1), (9003)	(4.2Y 7.5/1.1), (7044)	
Net weight			kg	9.5	31.5	
Compressor	r type & Quantity		_	_	RM-C5077SBE71(Rotary type) x 1	
Compressor motor (Starting method)			kW	_	0.75 (Inverter driven)	
Refrigerant oil (Amount, type)			l	_	0.30 (DIAMOND FREEZE MB75)	
Refrigerant (Type, amount, pre-charge length)			kg	R32 0.62 in outdoor unit (Incl. th	ne amount for the piping of 15m)	
Heat exchanger			1.3	Louver fins & inner grooved tubing	M fins & inner grooved tubing	
Refrigerant	<u> </u>			3 3	tronic expansion valve	
Fan type & 0				Tangential fan x 1	Propeller fan x 1	
	Starting method)		W	42 x1 (Direct drive)	24 x1 (Direct drive)	
		Cooling		Hi: 9.3 Me: 7.0 Lo: 5.9 ULo: 5.0	27.4	
Air flow		Heating	m³/min	Hi: 10.0 Me: 8.5 Lo: 6.5 ULo: 5.9	23.6	
Available ex	ternal static pressure	Trouting	Pa	0	0	
Outside air i	<u>'</u>		1 4	Not possible	_	
	ality / Quantity			Polypropylene net (Washable) x 2	_	
	ration absorber			Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)	
Electric hear						
Licotile fied	Remote control			Wireless rea	note control	
Operation	Room temperature control				ter thermostat	
control	Operation display			·	TIMER: Yellow	
	Operation display				ction, Overcurrent protection,	
Safety equip	oments			1 =	ection, Indoor fan motor error protection,	
				Heating overload protection(High press	ure control), Cooling overload protection	
	Refrigerant piping size (O.D)		mm	Liquid line: φ6.35 (1/4")	Gas line: φ 9.52 (3/8")	
	Connecting method			Flare connection	Flare connection	
	Attached length of piping		m	Liquid line: 0.54 / Gas line: 0.47		
Installation data	Insulation for piping			Necessary (Both s	ides), independent	
autu	Refrigerant line (one way) ler	ngth	m	Ma	x.20	
	Vertical height diff. between 0	D.U. and I.U.	m	Max.10 (Outdoor unit is higher)	/ Max.10 (Outdoor unit is lower)	
	Drain hose			Hose connectable (VP 16)	Hole φ20 x 2 pcs	
Drain pump, max lift height		mm		<u> </u>		
Recommended breaker size		Α	1	6		
L.R.A. (Lock	ed rotor ampere)		Α	3.2/3.0/2.9 (220/ 230/ 240V)	
Interconnec	• • •	number			ole) / Terminal block (Screw fixing type)	
IP number	L			IPX0	IPX4	
Standard ac	cessories			Mounting kit, Clean filter (Allergen clear filter x	I, Photocatalytic washable deodorizing filter x 1)	
Option parts					SC-BIKN2-E)	
1 10.17.23			1			

Notes (1) The data are measured at the following conditions.

Item	Indoor air t	emperature	Outdoor air	temperature	Standards
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	_	7℃	6°C	ISO5151-H1
Heating (H2)	20°C	_	2°C	1°C	ISO5151-H2

- (2) This air-conditioner is manufactured and tested in conformity with the ISO.
 (3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
 (4) Select the breaker size according to the own national standard.

			Model	SRK2	5ZS-W		
Item				Indoor unit SRK25ZS-W	Outdoor unit SRC25ZS-W		
Power source	:e			1 Phase, 220 - 240\	/, 50Hz / 220V, 60Hz		
	Nominal cooling capacity (rang	ge)	kW	2.5 (0.9 (Min.	.) - 3.1 (Max.))		
	Nominal heating capacity (rang	ge)	kW	3.2 (0.9 (Min.	.) - 4.5 (Max.))		
	Heating capacity (H2)		kW	_			
		Cooling		0.62 (0.1	9 - 0.90)		
	Power consumption	Heating	kW	0.74 (0.2	20 - 1.42)		
		Heating (H2)	1	-			
	Max power consumption			1.	65		
	D	Cooling		3.3 / 3.1 / 3.0 (220/ 230/ 240V)		
	Running current	Heating	Α	3.7 / 3.6 / 3.4 (220/ 230/ 240V)		
Operation	Inrush current, max current]	3.7 / 3.6 / 3.4 (220/	230/ 240V) Max. 9		
data	Power factor	Cooling	- %	8	66		
	Power factor	Heating	70	9	0		
	EER	Cooling		4.	03		
	COP	Heating]	4.	32		
	COP	Heating (H2)]	-	- -		
	Sound power level	Cooling		50	56		
	Souria power level	Heating		53	58		
	Sound pressure level	Cooling	dB(A)	Hi: 34 Me: 25 Lo: 22 ULo: 19	46		
	Souria pressure level	Heating		Hi: 36 Me: 29 Lo: 23 ULo: 19	46		
	Silent mode sound pressure level			_	Cooling:42 / Heating:43		
Exterior dime	ensions (Height x Width x Depth)	mm	290 x 870 x 230	540 x 780(+62) x 290		
Exterior app				Fine snow (Pure white)	Stucco white		
(Equivalent color : Munsell, RAL)				(8.0Y 9.3/0.1), (9003)	(4.2Y 7.5/1.1), (7044)		
Net weight			kg	9.5	31.0		
Compressor type & Quantity				_	RM-C5077SBE71(Rotary type) x 1		
Compressor motor (Starting method)			kW	-	0.75 (Inverter driven)		
Refrigerant oil (Amount, type)			l	-	0.30 (DIAMOND FREEZE MB75)		
Refrigerant (Type, amount, pre-charge length)			kg	,	ne amount for the piping of 15m)		
Heat exchanger			Louver fins & inner grooved tubing	M fins & inner grooved tubing			
Refrigerant of					tronic expansion valve		
Fan type & C				Tangential fan x 1	Propeller fan x 1		
Fan motor (S	Starting method)	1	W	42 x1 (Direct drive)	24 x1 (Direct drive)		
Air flow		Cooling	m³/min	Hi: 9.9 Me: 8.0 Lo: 5.9 ULo: 5.0	27.4		
		Heating		Hi: 11.3 Me: 8.7 Lo: 6.7 ULo: 5.9	23.6		
	ternal static pressure		Pa	0	0		
Outside air ii				Not possible	_		
	ality / Quantity			Polypropylene net (Washable) x 2	_		
	ration absorber			Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)		
Electric heat	1						
Operation	Remote control				mote control		
control	Room temperature control				ter thermostat		
	Operation display			,	TIMER: Yellow ction, Overcurrent protection,		
Safety equip	ements			Frost protection, Serial signal error prote	ection, Overcurrent protection, ection, Indoor fan motor error protection, ure control), Cooling overload protection		
	Refrigerant piping size (O.D)		mm	Liquid line: φ6.35 (1/4")	Gas line: φ 9.52 (3/8")		
	Connecting method			Flare connection	Flare connection		
Inetelleties	Attached length of piping		m	Liquid line : 0.54 / Gas line : 0.47			
Installation data	Insulation for piping			Necessary (Both s	ides), independent		
	Refrigerant line (one way) leng		m		x.20		
	Vertical height diff. between O.U. and I.U.		m	` '	/ Max.10 (Outdoor unit is lower)		
Drain hose			Hose connectable (VP 16)	Hole φ20 x 2 pcs			
Drain pump, max lift height		mm	_	_			
	ded breaker size		Α		6		
L.R.A. (Lock	ed rotor ampere)		Α	`	220/ 230/ 240V)		
Interconnect	ting wires Size x Core r	number		` -	ole) / Terminal block (Screw fixing type)		
IP number				IPX0	IPX4		
Standard ac					, Photocatalytic washable deodorizing filter x 1)		
Option parts				Interface kit (SC-BIKN2-E)		

Item	Indoor air t	emperature	Outdoor air	temperature	Standards
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	_	7℃	6°C	ISO5151-H1
Heating (H2)	20°C	_	2°C	1°C	ISO5151-H2

- (2) This air-conditioner is manufactured and tested in conformity with the ISO.
 (3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
 (4) Select the breaker size according to the own national standard.

			Model	SRK3	5ZS-W		
Item				Indoor unit SRK35ZS-W	Outdoor unit SRC35ZS-W		
Power source	:e			1 Phase, 220 - 240\	/, 50Hz / 220V, 60Hz		
	Nominal cooling capacity (range	ge)	kW	3.5 (0.9 (Min	.) - 4.0 (Max.))		
	Nominal heating capacity (range	ge)	kW	4.0 (0.9 (Min	.) - 5.0 (Max.))		
	Heating capacity (H2)		kW	_			
		Cooling		0.89 (0.1	7 - 1.24)		
	Power consumption	Heating	kW	0.94 (0.1	9 - 1.45)		
		Heating (H2)	1	-			
	Max power consumption			1.	65		
	D	Cooling		4.4 / 4.2 / 4.0 (220/ 230/ 240V)		
	Running current	Heating	Α	4.6 / 4.4 / 4.2 (220/ 230/ 240V)		
Operation	Inrush current, max current		1	4.6 / 4.4 / 4.2 (220/	230/ 240V) Max. 9		
data	Power factor	Cooling	- %	g	2		
	Power factor	Heating	70	9	3		
	EER	Cooling		3.	93		
	COP	Heating]	4.	26		
	COP	Heating (H2)		-	- -		
	Sound power level	Cooling		54	61		
	Souria power level	Heating		56	61		
	Sound pressure level	Cooling	dB(A)	Hi: 40 Me: 30 Lo: 26 ULo: 19	50		
	Souria pressure level	Heating		Hi: 41 Me: 36 Lo: 25 ULo:19	48		
	Silent mode sound pressure level			_	Cooling:45 / Heating:44		
Exterior dime	ensions (Height x Width x Depth)	mm	290 x 870 x 230	540 x 780(+62) x 290		
Exterior app				Fine snow (Pure white)	Stucco white		
(Equivalent color : Munsell, RAL)				(8.0Y 9.3/0.1), (9003)	(4.2Y 7.5/1.1), (7044)		
Net weight			kg	9.5	34.5		
Compressor type & Quantity				_	RM-B5077SBE2(Rotary type) x 1		
Compressor motor (Starting method)			kW	_	0.90 (Inverter driven)		
Refrigerant oil (Amount, type)			l	_	0.30 (DIAMOND FREEZE MB75)		
Refrigerant (Type, amount, pre-charge length)			kg	,	ne amount for the piping of 15m)		
Heat exchanger			Louver fins & inner grooved tubing	M fins & inner grooved tubing			
Refrigerant of					tronic expansion valve		
Fan type & C				Tangential fan x 1	Propeller fan x 1		
Fan motor (S	Starting method)	To ::	W	42 x1 (Direct drive)	24 x1 (Direct drive)		
Air flow		Cooling	m³/min	Hi: 11.3 Me: 8.7 Lo: 7.0 ULo: 5.0	31.5		
A ! - - - -		Heating	D-	Hi: 12.3 Me: 11.0 Lo: 7.0 ULo: 5.6	27.8		
	ternal static pressure		Pa	0	0		
Outside air ii				Not possible	_		
	ality / Quantity			Polypropylene net (Washable) x 2	Dubbar dans (for for mater 8 communical)		
Electric heat	ration absorber			Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)		
Electric rieat	1			— Window III			
Operation	Remote control Room temperature control				mote control ter thermostat		
control	Operation display				TIMER: Yellow		
	Operation display				ction, Overcurrent protection,		
Safety equip	oments			Frost protection, Serial signal error prote	ection, Indoor fan motor error protection, ure control), Cooling overload protection		
	Refrigerant piping size (O.D)		mm	Liquid line: φ6.35 (1/4")	Gas line: φ 9.52 (3/8")		
	Connecting method			Flare connection	Flare connection		
Inetelleties	Attached length of piping		m	Liquid line : 0.54 / Gas line : 0.47			
Installation data	Insulation for piping			Necessary (Both s	ides), independent		
	Refrigerant line (one way) leng		m		x.20		
		Vertical height diff. between O.U. and I.U.		,	/ Max.10 (Outdoor unit is lower)		
Drain hose			Hose connectable (VP 16)	Hole φ20 x 2 pcs			
Drain pump, max lift height		mm	_	_			
Recommended breaker size		Α		6			
•	ed rotor ampere)		Α	,	220/ 230/ 240V)		
Interconnect	ing wires Size x Core r	number		` •	ole) / Terminal block (Screw fixing type)		
IP number				IPX0	IPX4		
Standard ac					, Photocatalytic washable deodorizing filter x 1)		
Option parts				Interface kit (SC-BIKN2-E)		

Item	Indoor air t	emperature	Outdoor air	temperature	Standards
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	_	7°C	6°C	ISO5151-H1
Heating (H2)	20°C	_	2°C	1°C	ISO5151-H2

- (2) This air-conditioner is manufactured and tested in conformity with the ISO.
 (3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
 (4) Select the breaker size according to the own national standard.

			Model	SRK50	DZS-W	
Item				Indoor unit SRK50ZS-W	Outdoor unit SRC50ZS-W	
Power source	:e			1 Phase, 220 - 240\	/, 50Hz / 220V, 60Hz	
	Nominal cooling capacity (rang	ge)	kW	5.0 (1.3 (Min.	.) - 5.5 (Max.))	
	Nominal heating capacity (range)		kW	5.8 (1.3 (Min.) - 6.6 (Max.))	
	Heating capacity (H2)		kW	<u> </u>		
		Cooling		1.35 (0.2	9 - 1.80)	
	Power consumption	Heating	kW	1.56 (0.2	25 - 1.98)	
		Heating (H2)	1	-	_	
	Max power consumption			2.	68	
	Dunain a sumant	Cooling		6.2 / 5.9 / 5.7 (220/ 230/ 240V)	
	Running current	Heating	Α	7.2 / 6.9 / 6.6 (220/ 230/ 240V)	
Operation	Inrush current, max current	•	1	7.2 / 6.9 / 6.6 (220/ 2	30/ 240V) Max. 14.5	
data	Power factor	Cooling	- %	9	9	
	Power factor	Heating	70	9	9	
	EER	Cooling		3.	70	
	COP	Heating]	3.	72	
	COP	Heating (H2)]	-	-	
	Sound power level	Cooling		59	61	
	Souria power level	Heating		60	63	
	Sound pressure level	Cooling	dB(A)	Hi: 46 Me: 36 Lo: 29 ULo: 22	51	
	Souria pressure level	Heating		Hi: 46 Me: 37 Lo: 31 ULo: 24	52	
	Silent mode sound pressure level			_	Cooling:43 / Heating:45	
Exterior dime	ensions (Height x Width x Depth)	mm	290 x 870 x 230	595 x 780(+62) x 290	
Exterior app				Fine snow (Pure white)	Stucco white	
(Equivalent color : Munsell, RAL)				(8.0Y 9.3/0.1), (9003)	(4.2Y 7.5/1.1), (7044)	
Net weight			kg	10.0	36.0	
Compressor type & Quantity				_	9RS102XDA21(Rotary type) x 1	
Compressor motor (Starting method)			kW	_	1.50 (Inverter driven)	
Refrigerant oil (Amount, type)			l	_	0.32 (FW50S)	
Refrigerant (Type, amount, pre-charge length)			kg	,	ne amount for the piping of 15m)	
Heat exchanger			Louver fins & inner grooved tubing	M fins & inner grooved tubing		
Refrigerant of					tronic expansion valve	
Fan type & C				Tangential fan x 1	Propeller fan x 1	
Fan motor (S	Starting method)		W	42 x1 (Direct drive)	24 x1 (Direct drive)	
Air flow		Cooling	m³/min	Hi: 12.1 Me: 9.9 Lo: 7.4 ULo: 5.9	32.8	
		Heating		Hi: 13.9 Me: 11.2 Lo: 9.1 ULo: 7.4	32.8	
	ternal static pressure		Pa	0	0	
Outside air ii				Not possible	_	
	ality / Quantity			Polypropylene net (Washable) x 2	_	
	ration absorber			Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)	
Electric heat	1					
Operation	Remote control				mote control	
control	Room temperature control			1	er thermostat	
	Operation display			· · · · · · · · · · · · · · · · · · ·	TIMER: Yellow stion, Overcurrent protection,	
Safety equip	oments			Frost protection, Serial signal error prote	ection, Overcurrent protection, ection, Indoor fan motor error protection, ure control), Cooling overload protection	
	Refrigerant piping size (O.D)		mm	Liquid line: φ6.35 (1/4")	Gas line: φ 12.7 (1/2")	
	Connecting method			Flare connection	Flare connection	
Inotallatian	Attached length of piping		m	Liquid line: 0.54 / Gas line: 0.47	_	
Installation data	Insulation for piping			Necessary (Both s	ides), independent	
	Refrigerant line (one way) leng	ıth	m	Max	x.25	
	Vertical height diff. between O.U. and I.U.		m	Max.15 (Outdoor unit is higher)	/ Max.15 (Outdoor unit is lower)	
	Drain hose			Hose connectable (VP 16)	Hole φ20 x 2 pcs	
Drain pump, max lift height		mm	_	_		
Recommended breaker size		Α		0		
L.R.A. (Lock	ed rotor ampere)		Α	7.2 / 6.9 / 6.6 (220/ 230/ 240V)	
Interconnect	ting wires Size x Core n	umber		, -	le) / Terminal block (Screw fixing type)	
IP number				IPX0	IPX4	
Standard ac					, Photocatalytic washable deodorizing filter x 1)	
Option parts				Interface kit (SC-BIKN2-E)	

Item	Indoor air t	emperature	Outdoor air	temperature	Standards
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	_	7℃	6°C	ISO5151-H1
Heating (H2)	20°C	_	2°C	1°C	ISO5151-H2

- (2) This air-conditioner is manufactured and tested in conformity with the ISO.
 (3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
 (4) Select the breaker size according to the own national standard.

			Model	SRK20	ZS-WB		
Item			IVIOGEI	Indoor unit SRK20ZS-WB	Outdoor unit SRC20ZS-W		
Power source	e				/, 50Hz / 220V, 60Hz		
	Nominal cooling capacity (range	je)	kW	•	.) - 2.9 (Max.))		
	Nominal heating capacity (range		kW	, ,) - 4.3 (Max.))		
	Heating capacity (H2)		kW				
		Cooling		0.44 (0.1	9 - 0.80)		
	Power consumption	Heating	kW	0.59 (0.2			
		Heating (H2)	1	_			
	Max power consumption	1		1.	65		
		Cooling			220/ 230/ 240V)		
	Running current	Heating	A	,	220/ 230/ 240V)		
Operation	Inrush current, max current	1.1049	1	,	230/ 240V) Max. 9		
data	,	Cooling		,	9		
	Power factor	Heating	- %		5		
	EER	Cooling			55		
		Heating	1		58		
	COP	Heating (H2)	1		_		
		Cooling		48	56		
	Sound power level	Heating	1	50	56		
		Cooling	dB(A)	Hi: 34 Me: 25 Lo: 22 ULo: 19	45		
	Sound pressure level		-	Hi: 36 Me: 29 Lo: 23 ULo: 19	45		
	Heatin		-	HI. 36 WIE. 29 LO. 23 OLO. 19	Cooling:42 / Heating:43		
Exterior dim	Silent mode sound pressure le		mm				
	ensions (Height x Width x Depth)	<u> </u>	mm		540 x 780(+62) x 290		
Exterior app	earance color : Munsell, RAL)			Fine snow(8.0Y 9.3/0.1), (9003) Black (4.0PB 2.44/0.25), (9011)	Stucco white (4.2Y 7.5/1.1), (7044)		
Net weight			kg	9.5	31.0		
Compressor type & Quantity			ı.g	_	RM-C5077SBE71(Rotary type) x 1		
Compressor motor (Starting method)			kW		0.75 (Inverter driven)		
			e e		0.30 (DIAMOND FREEZE MB75)		
Refrigerant oil (Amount, type)			kg	P22 0.6 in outdoor unit (Incl. th	e amount for the piping of 15m)		
Refrigerant (Type, amount, pre-charge length)			l kg	Louver fins & inner grooved tubing	M fins & inner grooved tubing		
Heat exchanger Refrigerant control					tronic expansion valve		
Fan type & C				Tangential fan x 1	Propeller fan x 1		
	Starting method)		W	42 x1 (Direct drive)	24 x1 (Direct drive)		
r air motor (c	starting metriod)	Cooling	V V	Hi: 9.3 Me: 7.0 Lo: 5.9 ULo: 5.0	27.4		
Air flow		Heating	m³/min	Hi: 10.0 Me: 8.5 Lo: 6.5 ULo: 5.9	23.6		
Available ext	ternal static pressure	rieating	Pa	0	0		
Outside air ii	· · · · · · · · · · · · · · · · · · ·		ıα	Not possible	_		
	lity / Quantity			Polypropylene net (Washable) x 2	_		
-	ration absorber			Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)		
Electric heat				nubber sieeve (for fait filotor)			
Liectric rieat	Remote control			Wireless-remote control			
Operation	Room temperature control				er thermostat		
control	Operation display			•	TIMER: Yellow		
	Operation display			· · · · · · · · · · · · · · · · · · ·	ction, Overcurrent protection,		
Safety equip	ments				ection, Indoor fan motor error protection,		
, ,					ure control), Cooling overload protection		
	Refrigerant piping size (O.D)		mm	Liquid line: φ6.35 (1/4")	Gas line: φ 9.52 (3/8")		
	Connecting method			Flare connection	Flare connection		
	Attached length of piping		m	Liquid line: 0.54 / Gas line: 0.47	_		
Installation	Insulation for piping			Necessary (Both s	ides), independent		
data	Refrigerant line (one way) leng	th	m		x.20		
	Vertical height diff. between O.		m		/ Max.10 (Outdoor unit is lower)		
	Drain hose			Hose connectable (VP 16)	Hole φ20 x 2 pcs		
Drain pump, max lift height		mm	- Hole φ20 x 2 pcs				
Recommended breaker size		А		l 6			
	L.R.A. (Locked rotor ampere)				220/ 230/ 240V)		
Interconnect	· · · ·	umber	A		ele) / Terminal block (Screw fixing type)		
IP number	ING WILCO OIZE X OOIE II	a. i.bci		IPX0	IPX4		
Standard ac	cessories			Mounting kit, Clean filter (Allergen clear filter x 1	I .		
Option parts							
Option parts				Interface kit (SC-BIKN2-E)			

Item	Indoor air t	emperature	Outdoor air	temperature	Standards
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	_	7℃	6°C	ISO5151-H1
Heating (H2)	20°C	_	2°C	1°C	ISO5151-H2

- (2) This air-conditioner is manufactured and tested in conformity with the ISO.
 (3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
 (4) Select the breaker size according to the own national standard.

			Model	SRK25	ZS-WB	
Item				Indoor unit SRK25ZS-WB	Outdoor unit SRC25ZS-W	
Power source	ce			1 Phase, 220 - 240\	/, 50Hz / 220V, 60Hz	
	Nominal cooling capacity (rang	ge)	kW	2.5 (0.9 (Min.	.) - 3.1 (Max.))	
	Nominal heating capacity (rang	ge)	kW	3.2 (0.9 (Min.	.) - 4.5 (Max.))	
	Heating capacity (H2)		kW	<u> </u>		
		Cooling		0.62 (0.19 - 0.90)		
	Power consumption	Heating	kW	0.74 (0.2	20 - 1.42)	
		Heating (H2)		-	_	
	Max power consumption			1.	65	
	Running current	Cooling		3.3 / 3.1 / 3.0 (220/ 230/ 240V)	
	nulling current	Heating	Α	3.7 / 3.6 / 3.4 (220/ 230/ 240V)	
Operation	Inrush current, max current			3.7 / 3.6 / 3.4 (220/	230/ 240V) Max. 9	
data	Power factor	Cooling	- %	8	6	
		Heating	/"	9	0	
	EER	Cooling		4.	03	
	COP	Heating]	4.	32	
	001	Heating (H2)			_	
	Sound power level	Cooling		50	56	
	Courta power level	Heating		53	58	
	Sound pressure level	Cooling	dB(A)	Hi: 36 Me: 28 Lo: 23 ULo: 19	46	
	Courta procodio level	Heating		Hi: 39 Me: 30 Lo: 24 ULo: 19	46	
	Silent mode sound pressure le	vel		_	Cooling:42 / Heating:43	
	ensions (Height x Width x Depth)	mm	290 x 870 x 230	540 x 780(+62) x 290	
	Exterior appearance			Fine snow (8.0Y 9.3/0.1), (9003)	Stucco white	
(Equivalent color : Munsell, RAL)			Black (4.0PB 2.44/0.25), (9011)	(4.2Y 7.5/1.1), (7044)		
Net weight			kg	9.5	31.0	
Compressor type & Quantity		1347	_	RM-C5077SBE71(Rotary type) x 1		
Compressor motor (Starting method)		kW	_	0.75 (Inverter driven)		
Refrigerant oil (Amount, type)		l l		0.30 (DIAMOND FREEZE MB75)		
Refrigerant (Type, amount, pre-charge length)		kg	,	ne amount for the piping of 15m)		
Heat exchar	<u> </u>			Louver fins & inner grooved tubing	M fins & inner grooved tubing	
Refrigerant of					tronic expansion valve	
Fan type & C			W	Tangential fan x 1	Propeller fan x 1	
Fan motor (8	Starting method)	Cooling	VV	42 x1 (Direct drive) Hi: 9.9 Me: 8.0 Lo: 5.9 ULo: 5.0	24 x1 (Direct drive) 27.4	
Air flow			m³/min	Hi: 11.3 Me: 8.7 Lo: 6.7 ULo: 5.9	23.6	
Available ov	ternal static pressure	Heating	Pa	0	23.6	
Outside air i	· · · · · · · · · · · · · · · · · · ·		ı a	Not possible	_	
	ality / Quantity			Polypropylene net (Washable) x 2		
	ration absorber			Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)	
Electric heat				—		
Liootiio iioat	Remote control			Wireless-rer	note control	
Operation	Room temperature control				er thermostat	
control	Operation display			1	TIMER: Yellow	
	Горология			· · · · · · · · · · · · · · · · · · ·	tion, Overcurrent protection,	
Safety equip	oments				ection, Indoor fan motor error protection,	
					ure control), Cooling overload protection	
	Refrigerant piping size (O.D)		mm	Liquid line: φ6.35 (1/4")	Gas line: φ 9.52 (3/8")	
	Connecting method			Flare connection	Flare connection	
Installation Attached length of piping		m	Liquid line: 0.54 / Gas line: 0.47	_		
data	Insulation for piping		-		ides), independent	
	Refrigerant line (one way) leng		m		x.20	
	Vertical height diff. between O	.U. and I.U.	m	, ,	/ Max.10 (Outdoor unit is lower)	
Drain hose			Hose connectable (VP 16)	Hole φ20 x 2 pcs		
Drain pump, max lift height		mm				
	ded breaker size		A		6	
· · ·	ed rotor ampere)		A	,	220/ 230/ 240V)	
Interconnect	ting wires Size x Core r	umber		, -	ble) / Terminal block (Screw fixing type)	
IP number				IPX0	IPX4	
Standard ac			-		, Photocatalytic washable deodorizing filter x 1)	
Option parts				Interface kit (SC-BIKN2-E)	

Item	Indoor air t	emperature	Outdoor air	temperature	Standards
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	_	7℃	6°C	ISO5151-H1
Heating (H2)	20°C	_	2°C	1°C	ISO5151-H2

- (2) This air-conditioner is manufactured and tested in conformity with the ISO.
 (3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
 (4) Select the breaker size according to the own national standard.

			Model	SRK35	ZS-WB	
Item				Indoor unit SRK35ZS-WB	Outdoor unit SRC35ZS-W	
Power source	e			1 Phase, 220 - 240\	V, 50Hz / 220V, 60Hz	
	Nominal cooling capacity (rang	ge)	kW	3.5 (0.9 (Min	.) - 4.0 (Max.))	
	Nominal heating capacity (rang	ge)	kW	4.0 (0.9 (Min.) - 5.0 (Max.))		
	Heating capacity (H2)		kW			
		Cooling		0.89 (0.17 - 1.24)		
	Power consumption	Heating	kW	0.94 (0.1	19 - 1.45)	
	Heating (H2)			-	-	
	Max power consumption	Max power consumption		1.	65	
	Running current	Cooling		4.4 / 4.2 / 4.0 (220/ 230/ 240V)	
	Hulling Current	Heating	Α	4.6 / 4.4 / 4.2 (220/ 230/ 240V)	
Operation	Inrush current, max current			4.6 / 4.4 / 4.2 (220/	230/ 240V) Max. 9	
data	Power factor	Cooling	- %		92	
		Heating	/ 0		93	
	EER	Cooling			93	
	COP	Heating			26	
		Heating (H2)			_	
	Sound power level	Cooling		54	61	
		Heating		56	61	
	Sound pressure level	Cooling	dB(A)	Hi: 40 Me: 30 Lo: 26 ULo: 19	50	
		Heating		Hi: 41 Me: 36 Lo: 25 ULo:19	48	
	Silent mode sound pressure le			_	Cooling:45 / Heating:44	
	ensions (Height x Width x Depth)	mm	290 x 870 x 230	540 x 780(+62) x 290	
Exterior app				Fine snow (8.0Y 9.3/0.1), (9003)	Stucco white	
Net weight	color : Munsell, RAL)		lea	Black (4.0PB 2.44/0.25), (9011) 9.5	(4.2Y 7.5/1.1), (7044) 34.5	
	type & Quantity		kg	9.0	RM-B5077SBE2(Rotary type) x 1	
Compressor motor (Starting method)		kW		0.90 (Inverter driven)		
Refrigerant oil (Amount, type)		e e		0.30 (DIAMOND FREEZE MB75)		
Refrigerant (Type, amount, pre-charge length)		kg	P32 0.78 in outdoor unit (Incl. th	ne amount for the piping of 15m)		
Heat exchan			Ng	Louver fins & inner grooved tubing	M fins & inner grooved tubing	
Refrigerant of	<u> </u>			· · · · · · · · · · · · · · · · · · ·	tronic expansion valve	
Fan type & C				Tangential fan x 1	Propeller fan x 1	
	Starting method)		W	42 x1 (Direct drive)	24 x1 (Direct drive)	
	, , , , , , , , , , , , , , , , , , ,	Cooling		Hi: 11.3 Me: 8.7 Lo: 7.0 ULo: 5.0	31.5	
Air flow		Heating	m³/min	Hi: 12.3 Me: 11.0 Lo: 7.0 ULo: 5.6	27.8	
Available ext	ternal static pressure		Pa	0	0	
Outside air ii	·			Not possible	_	
Air filter, Qua	ality / Quantity			Polypropylene net (Washable) x 2	_	
Shock & vibr	ration absorber			Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)	
Electric heat	er			_	_	
On aus #!	Remote control			Wireless-re	mote control	
Operation control	Room temperature control			Microcomput	ter thermostat	
501100	Operation display				TIMER: Yellow	
Safety equip	oments			Frost protection, Serial signal error prote	ction, Overcurrent protection, ection, Indoor fan motor error protection, ure control), Cooling overload protection	
	Refrigerant piping size (O.D)		mm	Liquid line: φ6.35 (1/4")	Gas line: φ 9.52 (3/8")	
	Connecting method			Flare connection	Flare connection	
Located III	Attached length of piping		m	Liquid line: 0.54 / Gas line: 0.47	_	
Installation data	Insulation for piping			Necessary (Both s	ides), independent	
Juliu	Refrigerant line (one way) leng	gth	m	Max.20		
Vertical height diff. between O.U. and I.U.		m	Max.10 (Outdoor unit is higher)	/ Max.10 (Outdoor unit is lower)		
	Drain hose			Hose connectable (VP 16)	Hole φ20 x 2 pcs	
Drain pump, max lift height		mm	_	_		
	ded breaker size		Α		6	
L.R.A. (Lock	ed rotor ampere)		Α	,	220/ 230/ 240V)	
Interconnect	ting wires Size x Core r	number		` •	ole) / Terminal block (Screw fixing type)	
IP number				IPX0	IPX4	
Standard ac					1, Photocatalytic washable deodorizing filter x 1)	
Option parts				Interface kit (SC-BIKN2-E)	

Item	Indoor air t	emperature	Outdoor air	temperature	Standards
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	_	7°C	6°C	ISO5151-H1
Heating (H2)	20°C	_	2°C	1°C	ISO5151-H2

- (2) This air-conditioner is manufactured and tested in conformity with the ISO.
 (3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
 (4) Select the breaker size according to the own national standard.

			Model	SRK50	ZS-WB	
Item				Indoor unit SRK50ZS-WB	Outdoor unit SRC50ZS-W	
Power source	e			1 Phase, 220 - 240\	/, 50Hz / 220V, 60Hz	
	Nominal cooling capacity (rang	ge)	kW	5.0 (1.3 (Min.) - 5.5 (Max.))	
	Nominal heating capacity (range	ge)	kW	5.8 (1.3 (Min.) - 6.6 (Max.))	
	Heating capacity (H2)	,	kW	_		
		Cooling		1.35 (0.29 - 1.80)		
	Power consumption	Heating	kW	1.56 (0.2	25 - 1.98)	
	·	Heating (H2)	1 1	-	_	
	Max power consumption			2.	68	
		Cooling		6.2 / 5.9 / 5.7 (220/ 230/ 240V)	
	Running current	Heating	Α	7.2 / 6.9 / 6.6 (220/ 230/ 240V)	
Operation	Inrush current, max current		1 1	7.2 / 6.9 / 6.6 (220/ 2	30/ 240V) Max. 14.5	
data	Daniel factor	Cooling	0,	9	9	
	Power factor	Heating	- %	9	9	
	EER	Cooling		3.	70	
	000	Heating	1	3.	72	
	COP	Heating (H2)	1	-	=	
	0	Cooling		59	61	
	Sound power level	Heating	1 1	60	63	
	0	Cooling	dB(A)	Hi: 46 Me: 36 Lo: 29 ULo: 22	51	
	Sound pressure level	Heating	1	Hi: 46 Me: 37 Lo: 31 ULo: 24	52	
	Silent mode sound pressure le	vel	1	_	Cooling:43 / Heating:45	
Exterior dim	ensions (Height x Width x Depth))	mm	290 x 870 x 230	595 x 780(+62) x 290	
Exterior app	Exterior appearance			Fine snow (8.0Y 9.3/0.1), (9003)	Stucco white	
(Equivalent color : Munsell, RAL)			Black (4.0PB 2.44/0.25), (9011)	(4.2Y 7.5/1.1) , (7044)		
Net weight			kg	10.0	36.0	
Compressor type & Quantity			_	9RS102XDA21(Rotary type) x 1		
Compressor motor (Starting method)		kW	_	1.50 (Inverter driven)		
Refrigerant oil (Amount, type)		l	_	0.32 (FW50S)		
Refrigerant (Type, amount, pre-charge length)		kg	R32 1.05 in outdoor unit (Incl. th	ne amount for the piping of 15m)		
Heat exchar	nger			Louver fins & inner grooved tubing	M fins & inner grooved tubing	
Refrigerant of	control			Capillary tubes + Elec	tronic expansion valve	
Fan type & 0	Quantity			Tangential fan x 1	Propeller fan x 1	
Fan motor (S	Starting method)		W	42 x1 (Direct drive)	24 x1 (Direct drive)	
Air flow		Cooling	m³/min	Hi: 12.1 Me: 9.9 Lo: 7.4 ULo: 5.9	32.8	
All HOW		Heating	/	Hi: 13.9 Me: 11.2 Lo: 9.1 ULo: 7.4	32.8	
Available ex	ternal static pressure		Pa	0	0	
Outside air i	ntake			Not possible	_	
Air filter, Qua	ality / Quantity			Polypropylene net (Washable) x 2	_	
Shock & vib	ration absorber			Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)	
Electric heat	ter					
Operation	Remote control				note control	
control	Room temperature control			1	er thermostat	
	Operation display			· · · · · · · · · · · · · · · · · · ·	TIMER: Yellow	
Safety equip	oments			Frost protection, Serial signal error prote	ction, Overcurrent protection, ection, Indoor fan motor error protection, ure control), Cooling overload protection	
	Refrigerant piping size (O.D)		mm	Liquid line: φ6.35 (1/4")	Gas line: φ 12.7 (1/2")	
	Connecting method			Flare connection	Flare connection	
	Attached length of piping		m	Liquid line: 0.54 / Gas line: 0.47	_	
Installation data Insulation for piping				Necessary (Both s	ides), independent	
uaia	Refrigerant line (one way) leng	jth	m	Max	x.25	
Vertical height diff. between O.U. and I.U.			m	Max.15 (Outdoor unit is higher)	/ Max.15 (Outdoor unit is lower)	
	Drain hose			Hose connectable (VP 16)	Hole φ20 x 2 pcs	
Drain pump, max lift height		mm		<u> </u>		
Recommend	ded breaker size		А	2	0	
L.R.A. (Lock	ed rotor ampere)		Α	7.2 / 6.9 / 6.6 (220/ 230/ 240V)	
Interconnect	 	ıumber		,	le) / Terminal block (Screw fixing type)	
IP number	, L			IPX0	IPX4	
Standard ac	cessories			Mounting kit, Clean filter (Allergen clear filter x 1	, Photocatalytic washable deodorizing filter x 1)	
Option parts					SC-BIKN2-E)	
Option parts						

Item	Indoor air t	emperature	Outdoor air	temperature	Standards
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	_	7℃	6°C	ISO5151-H1
Heating (H2)	20°C	_	2°C	1°C	ISO5151-H2

- (2) This air-conditioner is manufactured and tested in conformity with the ISO.
 (3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
 (4) Select the breaker size according to the own national standard.

			Model	SRK20	ZS-WT		
Item				Indoor unit SRK20ZS-WT	Outdoor unit SRC20ZS-W		
Power source	e			1 Phase, 220 - 240V	/, 50Hz / 220V, 60Hz		
	Nominal cooling capacity (rang	ge)	kW	2.0 (0.9 (Min.) - 2.9 (Max.))		
	Nominal heating capacity (rang	ge)	kW	2.7 (0.9 (Min.) - 4.3 (Max.))		
	Heating capacity (H2)		kW				
		Cooling		0.44 (0.19 - 0.80)			
	Power consumption	Heating	kW	0.59 (0.2	0 - 1.40)		
	Heating (H2)			_	-		
	Max power consumption			1.0	65		
	Running current	Cooling		2.6 / 2.5 / 2.4 (2	220/ 230/ 240V)		
	nulling current	Heating	Α	3.2 / 3.0 / 2.9 (2	220/ 230/ 240V)		
Operation	Inrush current, max current			3.2 / 3.0 / 2.9 (220/	230/ 240V) Max. 9		
data	Power factor	Cooling	- %	7			
		Heating	/0	8	5		
	EER	Cooling		4.9	55		
	COP	Heating	_	4.9	58		
		Heating (H2)		-	-		
	Sound power level	Cooling	_	48	56		
	Country power level	Heating	_	50	56		
	Sound pressure level	Cooling	dB(A)	Hi: 34 Me: 25 Lo: 22 ULo: 19	45		
	·	Heating	_	Hi: 36 Me: 29 Lo: 23 ULo: 19	45		
	Silent mode sound pressure le	vel		_	Cooling:43 / Heating:45		
	ensions (Height x Width x Depth))	mm	290 x 870 x 230	540 x 780(+62) x 290		
Exterior app				Titanium gray (1.6Y 6.59/0.63), (7048)	Stucco white		
	(Equivalent color : Munsell, RAL)		<u> </u>	Black (4.0PB 2.44/0.25), (9011)	(4.2Y 7.5/1.1), (7044)		
Net weight		kg	9.5	31.0			
<u> </u>	Compressor type & Quantity Compressor mater (Starting method)		1.347	_	9RS102XDA21(Rotary type) x 1		
Compressor motor (Starting method)		kW	_	1.50 (Inverter driven)			
Refrigerant oil (Amount, type)		l	— — — — — — — — — — — — — — — — — — —	0.32 (FW50S)			
Refrigerant (Type, amount, pre-charge length)		kg	R32 0.62 in outdoor unit (Incl. th	11 0 /			
Heat exchan				-	M fins & inner grooved tubing		
Refrigerant of				Capillary tubes + Elect Tangential fan x 1			
Fan type & C	Starting method)		W		Propeller fan x 1 24 x1 (Direct drive)		
ran motor (3	Starting method)	Cooling	VV	42 x1 (Direct drive) Hi: 9.3 Me: 7.0 Lo: 5.9 ULo: 5.0	24 X1 (Direct drive) 27.4		
Air flow		Heating	m³/min	Hi: 10.0 Me: 8.5 Lo: 6.5 ULo: 5.9	23.6		
Available ox	ternal static pressure	rieating	Pa	0	0		
Outside air i	·		ıα	Not possible	_		
	ality / Quantity			Polypropylene net (Washable) x 2	<u> </u>		
	ration absorber			Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)		
Electric heat				—	—		
Liootiio iioat	Remote control			Wireless-rer	note control		
Operation	Room temperature control				er thermostat		
control	Operation display			RUN: Green ,			
	1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2			Compressor overheat protect			
Safety equip	oments			Frost protection, Serial signal error prote	ection, Indoor fan motor error protection,		
					ure control), Cooling overload protection		
	Refrigerant piping size (O.D)		mm	Liquid line: φ6.35 (1/4")	Gas line: φ 9.52 (3/8")		
	Connecting method			Flare connection	Flare connection		
Installation Attached length of piping		m	Liquid line: 0.54 / Gas line: 0.47	<u> </u>			
data	Insulation for piping			Necessary (Both sides), independent			
	Refrigerant line (one way) leng	·	m	Max			
Vertical height diff. between O.U. and I.U.		m	Max.10 (Outdoor unit is higher)	,			
Drain hose			Hose connectable (VP 16)	Hole φ20 x 2 pcs			
Drain pump, max lift height		mm	_				
	ded breaker size		A	1			
•	ed rotor ampere)		Α	3.2 / 3.0 / 2.9 (2	· · · · · · · · · · · · · · · · · · ·		
Interconnect	ting wires Size x Core n	number		, ,	le) / Terminal block (Screw fixing type)		
IP number				IPX0	IPX4		
Standard ac				Mounting kit, Clean filter (Allergen clear filter x 1			
Option parts			1	Interface kit (20-RIKN5-F)		

Item	Indoor air t	emperature	Outdoor air	temperature	Standards
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	_	7℃	6°C	ISO5151-H1
Heating (H2)	20°C	_	2°C	1°C	ISO5151-H2

- (2) This air-conditioner is manufactured and tested in conformity with the ISO.
 (3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
 (4) Select the breaker size according to the own national standard.

			Model	SRK25	ZS-WT		
Item			Wiodei	Indoor unit SRK25ZS-WT	Outdoor unit SRC25ZS-W		
Power source	e				/, 50Hz / 220V, 60Hz		
	Nominal cooling capacity (range	je)	kW	2.5 (0.9 (Min.			
	Nominal heating capacity (range		kW	, ,) - 4.5 (Max.))		
	Heating capacity (H2)	,-,	kW	<u> </u>			
		Cooling		0.62 (0.19 - 0.90)			
	Power consumption	Heating	kW	0.74 (0.2			
	Heating (H2)		1	_			
	Max power consumption			1.0	65		
		Cooling			220/ 230/ 240V)		
Operation	Running current	Heating	A	,	220/ 230/ 240V)		
	Inrush current, max current	1.10419	1	3.7 / 3.6 / 3.4 (220/			
data	,	Cooling		8			
	Power factor	Heating	%	9			
	EER	Cooling		4.1			
		Heating	1		32		
	COP	Heating (H2)	1		_		
		Cooling		50	56		
	Sound power level	Heating	1	53	58		
		Cooling	dB(A)	Hi: 36 Me: 28 Lo: 23 ULo: 19	46		
	Sound pressure level		ub(A)		46		
	Silent mode sound pressure le	Heating	-	Hi: 39 Me: 30 Lo: 24 ULo: 19	Cooling:42 / Heating:43		
Cutaviau dina					· · · · · · · · · · · · · · · · · · ·		
	ensions (Height x Width x Depth)	·	mm		540 x 780(+62) x 290		
Exterior app	earance color : Munsell, RAL)			Titanium gray (1.6Y 6.59/0.63), (7048) Black (4.0PB 2.44/0.25), (9011)	Stucco white (4.2Y 7.5/1.1), (7044)		
Net weight		kg	9.5	31.0			
Compressor type & Quantity		i ng	_	RM-C5077SBE71(Rotary type)			
Compressor motor (Starting method)		kW		0.75 (Inverter driven)			
Refrigerant oil (Amount, type)		l l		0.30 (DIAMOND FREEZE MB75)			
		kg	R32 0.62 in outdoor unit (Incl. th				
Refrigerant (Type, amount, pre-charge length) Heat exchanger		l kg	Louver fins & inner grooved tubing	M fins & inner grooved tubing			
Refrigerant of	<u> </u>			Capillary tubes + Elec			
Fan type & C				Tangential fan x 1	Propeller fan x 1		
	Starting method)		W	42 x1 (Direct drive)	24 x1 (Direct drive)		
r air motor (c	starting metriod)	Cooling	V V	Hi: 9.9 Me: 8.0 Lo: 5.9 ULo: 5.0	27.4		
Air flow		Heating	m³/min	Hi: 11.3 Me: 8.7 Lo: 6.7 ULo: 5.9	23.6		
Available ext	ternal static pressure	rreating	Pa	0	0		
Outside air ii	· · · · · · · · · · · · · · · · · · ·		ı a	Not possible	_		
	lity / Quantity			Polypropylene net (Washable) x 2	_		
-	ration absorber			Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)		
Electric heat				hubber sieeve (for fait filotor)			
Liectric rieat	Remote control			— Wireless-rer			
Operation	Room temperature control			Microcomput			
control	Operation display			·	TIMER: Yellow		
	Operation display				ction, Overcurrent protection,		
Safety equip	ments			Frost protection, Serial signal error prote			
7 - 100					ure control), Cooling overload protection		
	Refrigerant piping size (O.D)		mm	Liquid line: φ6.35 (1/4")	Gas line: φ 9.52 (3/8")		
	Connecting method			Flare connection	Flare connection		
	Attached length of piping		m	Liquid line: 0.54 / Gas line: 0.47	_		
	Installation Insulation for piping			Necessary (Both s	ides), independent		
data	Refrigerant line (one way) leng	th	m	Max			
	Vertical height diff. between O.		m	Max.10 (Outdoor unit is higher)	-		
Drain hose			Hose connectable (VP 16)	Hole φ20 x 2 pcs			
Drain pump, max lift height		mm		—			
Recommended breaker size		A	1	6			
	ed rotor ampere)		A		220/ 230/ 240V)		
Interconnect	· · ·	umber	<u> </u>		ele) / Terminal block (Screw fixing type)		
IP number	ING WILCO OIZE X OOIE II	G. 110Cl		IPX0	IPX4		
Standard ac	cessories		-	Mounting kit, Clean filter (Allergen clear filter x 1	I .		
Option parts							
Орноп рапѕ			1	Interface kit (SC-BIKN2-E)			

Item	Indoor air t	emperature	Outdoor air	temperature	Standards
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	_	7℃	6°C	ISO5151-H1
Heating (H2)	20°C	_	2°C	1°C	ISO5151-H2

- (2) This air-conditioner is manufactured and tested in conformity with the ISO.
 (3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
 (4) Select the breaker size according to the own national standard.

			Model	SRK35	ZS-WT	
Item				Indoor unit SRK35ZS-WT	Outdoor unit SRC35ZS-W	
Power source	ce			1 Phase, 220 - 240\	/, 50Hz / 220V, 60Hz	
	Nominal cooling capacity (rang	ge)	kW	3.5 (0.9 (Min.) - 4.0 (Max.))	
	Nominal heating capacity (rang	ge)	kW	4.0 (0.9 (Min.) - 5.0 (Max.))	
	Heating capacity (H2)		kW			
		Cooling		0.89 (0.1	7 - 1.24)	
	Power consumption	Heating	kW	0.94 (0.1	9 - 1.45)	
	Heating (H		1	-	_	
	Max power consumption			1.0	65	
	Cooling			4.4 / 4.2 / 4.0 (220/ 230/ 240V)	
	Running current	Heating	Α	4.6 / 4.4 / 4.2 (220/ 230/ 240V)	
Operation	Inrush current, max current		1	4.6 / 4.4 / 4.2 (220/	230/ 240 V) Max. 9	
data	B ()	Cooling	0.4	9	2	
	Power factor	Heating	%	9	3	
	EER	Cooling		3.9	93	
		Heating	1	4.:	26	
	COP	Heating (H2)	1	-	- -	
		Cooling		54	61	
	Sound power level	Heating	1	56	61	
		Cooling	dB(A)	Hi: 40 Me: 30 Lo: 26 ULo: 19	50	
	Sound pressure level	Heating	1 420,0	Hi: 41 Me: 36 Lo: 25 ULo:19	48	
	Silent mode sound pressure le		1		Cooling:45 / Heating:44	
Exterior dim	ensions (Height x Width x Depth)		mm	290 x 870 x 230	540 x 780(+62) x 290	
Exterior app		/	······	Titanium gray (1.6Y 6.59/0.63), (7048)	Stucco white	
(Equivalent color : Munsell, RAL)			Black (4.0PB 2.44/0.25), (9011)	(4.2Y 7.5/1.1), (7044)		
Net weight	· · · · · · · · · · · · · · · · · · ·		kg	9.5	34.5	
Compressor type & Quantity		Ť	_	RM-B5077SBE2(Rotary type) x 1		
Compressor motor (Starting method)		kW	_	0.90 (Inverter driven)		
Refrigerant oil (Amount, type)		l	_	0.30 (DIAMOND FREEZE MB75)		
Refrigerant (Type, amount, pre-charge length)		kg	R32 0.78 in outdoor unit (Incl. th	,		
Heat exchanger		1.5	Louver fins & inner grooved tubing	M fins & inner grooved tubing		
Refrigerant of				<u> </u>	tronic expansion valve	
Fan type & C				Tangential fan x 1	Propeller fan x 1	
	Starting method)		W	42 x1 (Direct drive) 24 x1 (Direct drive)		
		Cooling		Hi: 11.3 Me: 8.7 Lo: 7.0 ULo: 5.0	31.5	
Air flow		Heating	m³/min	Hi: 12.3 Me: 11.0 Lo: 7.0 ULo: 5.6	27.8	
Available ext	ternal static pressure	1	Pa	0	0	
Outside air i	· · · · · · · · · · · · · · · · · · ·			Not possible	_	
	ality / Quantity			Polypropylene net (Washable) x 2	_	
	ration absorber			Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)	
Electric heat				—	—	
2.000.00	Remote control			Wireless-rer	note control	
Operation	Room temperature control				er thermostat	
control	Operation display			RUN: Green ,		
	operation display				tion, Overcurrent protection,	
Safety equip	oments			Frost protection, Serial signal error prote		
			<u></u>		ure control), Cooling overload protection	
	Refrigerant piping size (O.D)		mm	Liquid line: φ6.35 (1/4")	Gas line: φ 9.52 (3/8")	
	Connecting method			Flare connection	Flare connection	
La akallar	Attached length of piping		m	Liquid line: 0.54 / Gas line: 0.47		
Installation data	Insulation for piping			Necessary (Both sides), independent		
uala	Refrigerant line (one way) leng	jth	m	Max	x.20	
	Vertical height diff. between O.		m	Max.10 (Outdoor unit is higher)	/ Max.10 (Outdoor unit is lower)	
	Drain hose			Hose connectable (VP 16)	Hole φ20 x 2 pcs	
Drain pump, max lift height		mm	_ ` ′	´ –		
Recommended breaker size		Α	1	6		
	ed rotor ampere)		A	4.6 / 4.4 / 4.2 (2		
Interconnect	 	ıumber	<u> </u>	,	ele) / Terminal block (Screw fixing type)	
IP number	5 C.E.C.X. 301011			IPX0	IPX4	
Standard ac	cessories				, Photocatalytic washable deodorizing filter x 1)	
Option parts				Interface kit (
Option parts			1	interface kit (

Item	Indoor air t	emperature	Outdoor air	temperature	Standards
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	_	7℃	6°C	ISO5151-H1
Heating (H2)	20°C	_	2°C	1°C	ISO5151-H2

- (2) This air-conditioner is manufactured and tested in conformity with the ISO.
 (3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
 (4) Select the breaker size according to the own national standard.

		Model	SRK50	ZS-WT		
Item				Indoor unit SRK50ZS-WT Outdoor unit SRC50ZS-W		
Power source	e			1 Phase, 220 - 240\	/, 50Hz / 220V, 60Hz	
	Nominal cooling capacity (rang	ge)	kW	5.0 (1.3 (Min.	.) - 5.5 (Max.))	
	Nominal heating capacity (rang	ge)	kW	5.8 (1.3 (Min.	.) - 6.6 (Max.))	
	Heating capacity (H2)		kW	-	_	
		Cooling		1.35 (0.2	9 - 1.80)	
	Power consumption	Heating	kW	1.56 (0.2	25 - 1.98)	
		Heating (H2)		-	_	
	Max power consumption			2.0	68	
	Running current	Cooling		6.2 / 5.9 / 5.7 (220/ 230/ 240V)	
	Hulling Current	Heating	A	7.2 / 6.9 / 6.6 (220/ 230/ 240V)	
Operation	Inrush current, max current			7.2 / 6.9 / 6.6 (220/ 2	230/ 240V) Max. 14.5	
data	Power factor	Cooling	- %	9	9	
		Heating	/0	9	9	
	EER	Cooling		3.	70	
	COP	Heating		3.	72	
		Heating (H2)			_	
	Sound power level	Cooling		59	61	
	Country power level	Heating		60	63	
	Sound pressure level	Cooling	dB(A)	Hi: 46 Me: 36 Lo: 29 ULo: 22	51	
	<u> </u>	Heating		Hi: 46 Me: 37 Lo: 31 ULo: 24	52	
	Silent mode sound pressure le	vel		_	Cooling:45 / Heating:44	
	ensions (Height x Width x Depth))	mm	290 x 870 x 230	595 x 780(+62) x 290	
Exterior app				Titanium gray (1.6Y 6.59/0.63), (7048)	Stucco white	
(Equivalent color : Munsell, RAL)			Black (4.0PB 2.44/0.25), (9011)	(4.2Y 7.5/1.1), (7044)		
Net weight		kg	10.0	36.0		
Compressor type & Quantity			1387	_	9RS102XDA21(Rotary type) x 1	
Compressor motor (Starting method)		kW	_	1.50 (Inverter driven)		
Refrigerant oil (Amount, type)		l l		0.32 (FW50S)		
	Type, amount, pre-charge length)	kg	R32 1.05 in outdoor unit (Incl. th	, , ,	
Heat exchanger Refrigerant control			Louver fins & inner grooved tubing	M fins & inner grooved tubing		
				Tangential fan x 1	tronic expansion valve	
Fan type & C	Starting method)		W	42 x1 (Direct drive)	Propeller fan x 1	
ran motor (3	starting metriod)	Cooling	VV	Hi: 12.1 Me: 9.9 Lo: 7.4 ULo: 5.9	24 x1 (Direct drive) 32.8	
Air flow		Heating	m³/min	Hi: 13.9 Me: 11.2 Lo: 9.1 ULo: 7.4	32.8	
Available ex	ternal static pressure	Heating	Pa	0	0	
Outside air i	·		1 α	Not possible	_	
	ality / Quantity			Polypropylene net (Washable) x 2	_	
-	ration absorber			Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)	
Electric heat				—	—	
	Remote control			Wireless-rer	note control	
Operation	Room temperature control				er thermostat	
control	Operation display			RUN: Green , TIMER: Yellow		
oporation display				ction, Overcurrent protection,		
Safety equipments			Frost protection, Serial signal error prote	ection, Indoor fan motor error protection,		
				ure control), Cooling overload protection		
	Refrigerant piping size (O.D)		mm	Liquid line: φ6.35 (1/4")	Gas line: φ 12.7 (1/2")	
	Connecting method			Flare connection	Flare connection	
Installation	Attached length of piping		m	Liquid line : 0.54 / Gas line : 0.47 — Necessary (Both sides), independent		
data	Insulation for piping			• `		
	Refrigerant line (one way) length		m	Max		
Vertical height diff. between O.U. and I.U.		m	Max.15 (Outdoor unit is higher)	, ,		
Drain hose			Hose connectable (VP 16)	Hole φ20 x 2 pcs		
Drain pump, max lift height		mm	_			
Recommended breaker size		A		6		
· · ·	ed rotor ampere)		Α	7.2 / 6.9 / 6.6 (· · · · · · · · · · · · · · · · · · ·	
Interconnect	ing wires Size x Core n	umber		, ,	ble) / Terminal block (Screw fixing type)	
IP number				IPX0	IPX4	
Standard ac					, Photocatalytic washable deodorizing filter x 1)	
Option parts				Interface kit (50-BINN2-E)	

Item	Indoor air temperature		Outdoor air	temperature	Standards
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	_	7℃	6°C	ISO5151-H1
Heating (H2)	20°C	_	2°C	1°C	ISO5151-H2

- (2) This air-conditioner is manufactured and tested in conformity with the ISO.
 (3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
 (4) Select the breaker size according to the own national standard.

Packing material weight list


Unit: kg

	Material		Packing			Danar	Me	tal		
Model		Gross Weight	Parts weight (Total)	Glass	Plastic	Paper and board	Aluminium	Steel	Wood	Other
	SRK20ZS-W	11.5	1.21	0.00	0.33	0.88	0.00	0.00	0.00	0.00
	SRK25ZS-W	11.5	1.21	0.00	0.33	0.88	0.00	0.00	0.00	0.00
	SRK35ZS-W	11.5	1.21	0.00	0.33	0.88	0.00	0.00	0.00	0.00
	SRK50ZS-W	12.0	1.21	0.00	0.33	0.88	0.00	0.00	0.00	0.00
	SRK20ZS-WB	11.5	1.21	0.00	0.33	0.88	0.00	0.00	0.00	0.00
Indoor	SRK25ZS-WB	11.5	1.21	0.00	0.33	0.88	0.00	0.00	0.00	0.00
Indoor	SRK35ZS-WB	11.5	1.21	0.00	0.33	0.88	0.00	0.00	0.00	0.00
	SRK50ZS-WB	12.0	1.21	0.00	0.33	0.88	0.00	0.00	0.00	0.00
	SRK20ZS-WT	11.5	1.21	0.00	0.33	0.88	0.00	0.00	0.00	0.00
	SRK25ZS-WT	11.5	1.21	0.00	0.33	0.88	0.00	0.00	0.00	0.00
	SRK35ZS-WT	11.5	1.21	0.00	0.33	0.88	0.00	0.00	0.00	0.00
	SRK50ZS-WT	12.0	1.21	0.00	0.33	0.88	0.00	0.00	0.00	0.00
	SRC20ZS-W	32.5	2.04	0.00	0.35	1.69	0.00	0.00	0.00	0.00
Outdoor	SRC25ZS-W	32.5	2.04	0.00	0.35	1.69	0.00	0.00	0.00	0.00
Outdoor	SRC35ZS-W	36.0	2.04	0.00	0.35	1.69	0.00	0.00	0.00	0.00
	SRC50ZS-W	38.0	2.13	0.00	0.35	1.78	0.00	0.00	0.00	0.00

2. EXTERIOR DIMENSIONS

(1) Indoor units

Models SRK20ZS-W, 25ZS-W, 35ZS-W, 50ZS-W SRK20ZS-WB, 25ZS-WB, 35ZS-WB, 50ZS-WB SRK20ZS-WT, 25ZS-WT, 35ZS-WT, 50ZS-WT



(2) Outdoor units

Models SRC20ZS-W, 25ZS-W, 35ZS-W

The unit must be fixed with anchor bolts. An anchor bolt must not The unit must not be surrounded by walls on the four sides. protrude more than 15mm.

If the unit is installed in the location where there is a possibility of strong winds, place the unit such that the direction of air from the outlet gets perpendicular to the wind direction.

 $\widehat{\mathfrak{S}}$

Leave 200mm or more space above the unit.

The wall height on the outlet side should be 1200mm or less.

<u>4</u> <u>6</u> <u>6</u>

The model name label is attached on the right side of the unit.

√ Inlet 슬블


Installation space	280 or more	100 or more	80 or more	250 or more
	L1	77	ЕП	L4


Terminal block	138.4
മ്	

otes (1) (2)

$^{\circ}$	•	
$\overline{}$	•	
	•	

Content tion (gas side) tion (liquid side) hole		(Flare)	(Flare)		es	ices
Content ion (gas side) ition (liquid side) hole		(3/8")	(1/4")		0x2 plac	12x4 pla
Content ervice valve connection (gas side) ervice valve connection (liquid side) ipe / cable draw-out hole rain discharge hole nchor bolt hole		ϕ 9.52			φ5	M10-
ervice valve connection ervice valve connection ipe / cable draw-out hole rain discharge hole nchor bolt hole	Content	(gas side)	(liquid side)	4		
		ervice valve connection	ervice valve connection	ipe/cable draw-out hole	rain discharge hole	nchor bolt hole





RCV000Z036

Unit:mm

Model SRC50ZS-W

The unit must be fixed with anchor boits. An afficior boit must protrude more than 15mm.

not

If the unit is installed in the location where there is a possibility of strong winds, place the unit such that the direction of air from the

 $\widehat{\mathfrak{S}}$

outlet gets perpendicular to the wind direction.

Leave 200mm or more space above the unit.

The wall height on the outlet side should be 1200mm or less.

9 (2) (9


The model name label is attached on the right side of the unit. / Inlet Installation space 280 or more 100 or more 80 or more 250 or more \mathbb{C} \Box 4


> 40° Terminal block 40° 33.5 138.4

Notes (1)

Content	
10100	
Service valve connection (gas side) $\phi = 12.7 (1/2")$ (Flare)	ϕ 12.7 (1/2") (Flare)
Service valve connection (liquid side) ϕ 6.35 (1/4")	ϕ 6.35 (1/4") (Flare)
Pipe / cable draw-out hole	
Drain discharge hole	φ20×2 places
Anchor bolt hole	M10-12×4 places

⋖ В ပ ш







RCV000Z037

(3) Remote control (a) Wireless remote control

Unit: mm







(b) Wired remote control (Option parts) Interface kit (SC-BIKN2-E) is required to use the wired remote control.

Model RC-EX3A

Dimensions (Viewed from front)



Installation space



• Do not install the remote control at following places.

- (1) It could cause break-down or deformation of remote control.
 - · Where it is exposed to direct sunlight
 - Where the ambient temperature becomes 0 °C or below, or 40 °C or above
 - · Where the surface is not flat
 - · Where the strength of installation area is insufficient
- (2) Moisture may be attached to internal parts of the remote control, resulting in a display failure.
 - · Place with high humidity where condensation occurs on the remote control
 - · Where the remote control gets wet
- (3) Accurate room temperature may not be detected using the temperature sensor of the remote
 - · Where the average room temperature cannot be detected
 - · Place near the equipment to generate heat
 - · Place affected by outside air in opening/closing the door
 - · Place exposed to direct sunlight or wind from air-conditioner

disrupt medical activities, video broadcasting or cause noise interference.

- · Where the difference between wall and room temperature is large
- (4) When you are using the automatic grille up and down panel in the IU, you may not be able to confirm the up and down motion.
 - · Where the IU cannot be visually confirmed

• When installing the unit at a hospital, telecommunication facility, etc., take measures to suppress electric noises.

It could cause malfunction or break-down due to hazardous effects on the inverter, private power generator, high frequency medical equipment, radio communication equipment, etc. The influences transmitted from the remote control to medical or communication equipment could

Adapted RoHS directive

R/C cable:0.3mm²x2 cores

When the cable length is longer than 100 m, the max size for wires used in the R/C case

is 0.5 mm². Connect them to wires of larger

size near the outside of R/C. When wires are

connected, take measures to prevent water,

0.5 mm² x 2 cores

0.75 mm² x 2 cores

1.25 mm² x 2 cores

2.0 mm² x 2 cores

etc. from entering inside.


≤ 200 m

≤ 300m

≤ 400m

≤ 600m

PJZ000Z333



Wiring specifications

(1) If the prolongation is over 100m, change to the size below. But, wiring in the remote control case should be under 0.5mm². Change the wire size outside of the case according to wire connecting. Waterproof treatment is necessary at the wire connecting section. Be careful about contact failure.


Length	Wiring thickness
100 to 200m	0.5mm ² ×2 cores
Under 300m	0.75mm ² ×2 cores
Under 400m	1.25mm ² ×2 cores
Under 600m	2.0mm ² ×2 cores

PJZ000Z295

3. ELECTRICAL WIRING

(1) Indoor units


Models SRK20ZS-W, 25ZS-W, 35ZS-W, 50ZS-W SRK20ZS-WB, 25ZS-WB, 35ZS-WB, 50ZS-WB SRK20ZS-WT, 25ZS-WT, 35ZS-WT, 50ZS-WT



RWA000Z416


(2) Outdoor units

Models SRC20ZS-W, 25ZS-W, 35ZS-W



RWC000Z315

Model SRC50ZS-W



RWC000Z316

4. NOISE LEVEL


(1) Sound power level Model SRK20ZS-W, -WB, -WT

 Model
 SRK20ZS-W,WB,WT

 Noise
 Cooling
 48 dB(A)


 Level
 Heating
 50 dB(A)

Condition	IS05151 T1/H1
MODE	Rated capacity value




(Outdoor unit)

(outdoor dirrey						
Model	S	SRC20ZS-W				
Noise	Cooling	56 dB(A)				
Laval	Heating	56 dB(A)				




(Indo	or unit)			
Mode	:I S	SRK25	ZS-W,V	VB,WT
Nois	e Cool	ing	50	dB(A)
Lave	I Heat	ina	E 2	AD/A)

Condition	ISO5151 T1/H1
MODE	Rated capacity value




(Outdoor unit)

(000001	dill 0/	
Model	SRC25ZS-W	
Noise	Cooling	56 dB(A)
Level	Heating	58 dB(A)




(Indoor	unit)		
Model	SRK	35ZS-W,V	VB,WT
Noise	Cooling	54	dB(A)
امعما	Heating	56	dB(A)

Condition	IS05151 T1/H1
MODE	Rated capacity value




	1 (16)6 1	r 111	nit)
100	tdoo		/

Model	SRC35ZS-W	
Noise	Cooling	61 dB(A)
Level	Heating	61 dB(A)





(Indoor	unit)	
Model	SRK	50ZS-W,WB,WT
Noise	Cooling	59 dB(A)
Level	Heating	60 dB(A)

Condition	IS05151 T1/H1
MODE	Rated capacity value



(Outdoor unit)ModelSRC50ZS-WNoiseCooling61 dB(A)LevelHeating63 dB(A)






Condition ISO5151 T1/H1

MODE Rated capacity value

<u>(Indoor</u>	unit)	
Model	SRK	20ZS-W,WB,WT
Noise	Cooling	34 dB(A)
Level	Heating	36 dB(A)






(Outdoor unit)


Model	S	RC20ZS-W
Noise	Cooling	45 dB(A)
Level	Heating	45 dB(A)

 Mike position: at highest noise level in position as mentioned below Distance from front side 1m




Model SRK25ZS-W, -WB, -WT

Condition	ISO5151 T1/H1	
MODE	Rated capacity value	
●Mike position		









(Outdoor unit)

Model	SRC25ZS-W		
Noise	Cooling	46 dB(A)	
Level	Heating	46 dB(A)	

 Mike position: at highest noise level in position as mentioned below Distance from front side 1m




Model SRK35ZS-W, -WB, -WT




(Outdoor unit)

Model	SRC35ZS-W		 Mike position: at highest noise level in position as mentioned below Distance from front side 1m
Noise	Cooling	50 dB(A)	Distance nonn nont side inn
Level	Heating	48 dB(A)	

Mid octave band frequency (Hz)




Model SRK50ZS-W, -WB, -WT





(Outdoor unit)


Model	SRC50ZS-W		 Mike position: at highest noise level in position as mentioned below Distance from front side 1m
Noise	Cooling	51 dB(A)	Distance from front side fill
Level	Heating	52 dB(A)]





(b) Each fan speed mode Condition IS05151 T1/H1 MODE Hi ■Mike position (Indoor unit) Mode I SRK20ZS-W,WB,WT Noise Cooling 34 dB(A) Mike position (Center & low points) Level Heating 36 dB(A) ×····· Cooling O Heating 70 70 N70 60 60 Sound pressure level (dB) **N60** (Standard 2x10-5Pa) 50 50 **N50** 40 40 **N40** 30 N30 20 20 **N20** 10 10 1000 63 125 250 500 2000 4000 8000 Mid octave band frequency (Hz) MODE Me Mike position (Indoor unit) SRK20ZS-W,WB,WT Mode I 1m Noise Cooling 25 dB(A) Mike position (Center & low points) Heating Level 29 dB(A) ... Cooling O Heating 70 70 N70 60 60 Sound pressure level (dB) **N60** (Standard 2x10⁻⁵Pa) 50 **N50** 40 **N40** 30 N30 20 20 **N20** 10 3000 10 1000 63 125 250 500 2000 4000 Mid octave band frequency (Hz)

















Condition ISO5151 T1/H1

(Outdoor unit)

Model	SRC20ZS-W						
Noise	Cooling	42 dB(A)					
Level	Heating	43 dB(A)					

Mike position: at highest noise level in position as mentioned below Distance from front side 1m

Noise	Cooling		dB(A)			MODE	I	0:1
Level	Heating	43	dB(A)			MODE		Silent
70				×	Cooling	0—	Heating	
70				***************************************		·	N70	70
60 P			**********	************			N60	60
Sound pressure level (dB) (Standard 2x10*Pa) S S				*******			NEO	50
ssure ard 2x	*		A-2-				N50	40
Ind pre Stand							N40	
NOS 30							N30	30
20							×	20
10							N20	10
10	63	125	250	500 10	000 20	000 4	000 80	000
	Mid octave band frequency (Hz)							

(Outdoor unit)

(Ou Lucoi	uiii t/	
Model	9	SRC25ZS-W
Noise	Cooling	42 dB(A)
Level	Heating	43 dB(A)

Mike position: at highest noise level in position as mentioned below Distance from front side 1m

MODE Silent Cooling Heating 70 70 N70 60 60 Sound pressure level (dB) **N60** (Standard 2x10⁵Pa) 50 **N50** 40 **N40** 30 30 N30 20 20 **N20** 10 800010 63 125 250 500 1000 2000 4000 Mid octave band frequency (Hz)

Condition IS05151 T1/H1

(Outdoor unit)

Model	SRC35ZS-W						
Noise	Cooling	45 dB(A)					
Level	Heating	44 dB(A)					

Mike position: at highest noise level in position as mentioned below Distance from front side 1m

Noise	Cooling	45 dB(A)		HODE		0:1+
Level	Heating	44 dB(A)]	MODE		Silent
70		, , ,	× Cooling	0-	Heating	a 70
60					N70	
el (dB) Pa)					N60	60
Sound pressure level (dB) (Standard 2x10*Pa) S S					N50	50
nd press Standar &				***************************************	N40	40
Nos 30					N30	30
20					N20	20
10	63	125 250	500 1000 2	2000 40	000 80	10 000
Mid octave band frequency (Hz)						


(Outdoor unit) Mode I SRC50ZS-W Noise Cooling 43 dB(A)

Mike position: at highest noise level in position as mentioned below Distance from front side 1m


MODE Silent Level Heating 45 dB(A) ···· Cooling Heating 70 70 N70 60 60 Sound pressure level (dB) (Standard 2x10*Pa) (Standard 2x10*Pa) Standard 2x10*Pa **N60** 50 **N50** 40 **N40** 30 20 20 **N20** 10 800010 125 250 500 1000 2000 63 4000 Mid octave band frequency (Hz)

5. PIPING SYSTEM


Models SRK20ZS-W, 25ZS-W SRK20ZS-WB, 25ZS-WB SRK20ZS-WT, 25ZS-WT



Models SRK35ZS-W SRK35ZS-WB SRK35ZS-WT



Models SRK50ZS-W SRK50ZS-WB SRK50ZS-WT



6. RANGE OF USAGE & LIMITATIONS


Model	SRK20,25,35ZS-W SRK20,25,35ZS-WB SRK20,25,35ZS-WT	SRK50ZS-W SRK50ZS-WB SRK50ZS-WT			
Indoor return air temperature (Upper, lower limits)	Cooling operation : Approximately 18 to 32℃ D.B. Heating operation : Approximately 10 to 30℃ D.B. (Refer to the selection chart)				
Outdoor air temperature (Upper, lower limits)	Cooling operation: Approximately -15 to 46°C D.B. Heating operation: Approximately -15 to 24°C D.B. (Refer to the selection chart)				
Refrigerant line (one way) length	Max. 20m	Max. 25m			
Vertical height difference between outdoor unit and indoor unit	Max. 10m Max. 15m (Outdoor unit is higher) (Outdoor unit is higher) Max. 15m (Outdoor unit is lower) (Outdoor unit is lower)				
Power source voltage	Rating ±10%				
Voltage at starting	Min. 85% of rating				
Frequency of ON-OFF cycle	Max. 4 times/h (Inching prevention 10 minutes)	Max. 7 times/h (Inching prevention 5 minutes)			
ON and OFF interval	Min. 3 minutes				

Selection chart

Correct the cooling and heating capacity in accordance with the conditions as follows. The net cooling and heating capacity can be obtained in the following way.

Net capacity = Capacity shown on specification \times Correction factors as follows.

(1) Coefficient of cooling and heating capacity in relation to temperatures



(2) Correction of cooling and heating capacity in relation to one way length of refrigerant piping

It is necessary to correct the cooling and heating capacity in relation to the one way piping length between the indoor and outdoor units.

Piping length [m]	7	10	15	20	25
Cooling	1.0	0.99	0.975	0.965	0.95
Heating	1.0	1.0	1.0	1.0	1.0


(3) Correction relative to frosting on outdoor heat exchanger during heating

In additions to the foregoing corrections (1), (2) the heating capacity needs to be adjusted also with respect to the frosting on the outdoor heat exchanger.

Air inlet temperature of outdoor unit in °CWB	-15	-10	-9	-7	-5	-3	-1	1	3	5 or more
Adjustment coefficient	0.95	0.95	0.94	0.93	0.91	0.88	0.86	0.87	0.92	1.00

How to obtain the cooling and heating capacity

Example : The net cooling capacity of the model SRK35ZS-W with the piping length of 15m, indoor wet-bulb temperature at 19.0° C and outdoor dry-bulb temperature 35° C is



7. CAPACITY TABLES

Models SRK20ZS-W, -WB, -WT

Cooling mode

Model	s SRK2	20 Z \$	S-W	, -W	В, -	Cooling mode					(kW)				
	0.11						Indo	or air t	empera	ture					
Air flow	Outdoor air	21°0	CDB	23°C	CDB	26°0	DB	27°C	DB	28°C	DB	31°0	CDB	33°C	DB
All llow	temperature	14°C	CWB	16°C	WB	18°C	WB	19°C	WB	20°C	WB	22°C	WB	24°C	WB
	tomporataro	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
	10	2.25	2.11	2.36	2.08	2.45	2.19	2.49	2.17	2.53	2.15	2.60	2.25	2.67	2.20
	12	2.21	2.09	2.32	2.06	2.41	2.18	2.45	2.16	2.50	2.14	2.58	2.24	2.65	2.19
	14	2.17	2.06	2.28	2.04	2.38	2.17	2.42	2.15	2.47	2.12	2.55	2.23	2.62	2.18
	16	2.13	2.02	2.24	2.02	2.34	2.15	2.39	2.13	2.43	2.11	2.52	2.22	2.59	2.18
	18	2.08	1.98	2.19	2.01	2.30	2.14	2.35	2.12	2.40	2.10	2.49	2.21	2.56	2.17
	20	2.04	1.94	2.15	1.99	2.26	2.12	2.31	2.10	2.36	2.08	2.45	2.20	2.53	2.16
	22	1.99	1.89	2.10	1.97	2.22	2.10	2.28	2.09	2.32	2.07	2.42	2.19	2.50	2.14
Hi	24	1.94	1.85	2.05	1.95	2.18	2.07	2.24	2.08	2.28	2.06	2.38	2.18	2.47	2.14
9.3	26	1.90	1.80	2.01	1.91	2.14	2.03	2.20	2.06	2.24	2.04	2.35	2.17	2.43	2.13
(m³/min)	28	1.85	1.75	1.96	1.86	2.09	1.99	2.15	2.05	2.20	2.03	2.31	2.15	2.40	2.12
	30	1.79	1.70	1.90	1.81	2.05	1.94	2.11	2.01	2.16	2.01	2.27	2.14	2.36	2.09
	32	1.74	1.65	1.85	1.76	2.00	1.90	2.07	1.96	2.12	2.00	2.23	2.12	2.32	2.08
	34	1.69	1.60	1.80	1.71	1.95	1.85	2.02	1.92	2.07	1.97	2.19	2.08	2.28	2.07
	35	1.66	1.58	1.77	1.68	1.93	1.83	2.00	1.90	2.05	1.94	2.17	2.06	2.26	2.06
	36	1.63	1.55	1.74	1.65	1.90	1.81	1.98	1.88	2.02	1.92	2.15	2.04	2.24	2.05
	38	1.58	1.50	1.68	1.60	1.85	1.76	1.93	1.83	1.98	1.88	2.11	2.00	2.20	2.04
	39	1.55	1.47	1.66	1.57	1.83	1.74	1.91	1.81	1.95	1.85	2.08	1.98	2.18	2.04

	Heating mode (HC) (kW										
Air flow	Outdoor air		Indoor air temperature								
1 1	temperature	16°CDB	18°CDB	20°CDB	22°CDB	24°CDB					
	-15°CWB	1.66	1.63	1.59	1.55	1.52					
1	-10°CWB	1.88	1.85	1.82	1.78	1.74					
1	-5°CWB	2.04	2.01	1.97	1.94	1.91					
Hi	0°CWB	2.13	2.10	2.07	2.04	2.01					
10.0	5°CWB	2.72	2.69	2.67	2.62	2.58					
(m³/min)	6°CWB	2.76	2.73	2.70	2.67	2.63					
	10°CWB	2.94	2.91	2.89	2.85	2.82					
	15°CWB	3.20	3.17	3.14	3.11	3.08					
	20°CWB	3.43	3.41	3.39	3.35	3.32					

Models SRK25ZS-W, -WB, -WT

Cooling	mode
---------	------

	0.44						Indo	or air t	empera	ture					
Air flow	Outdoor air	21°0	DB	23°0	DB	26°0	DB	27°C	DB	28°0	CDB	31°0	DB	33°C	DB
All llow	temperature	14°C	WB	16°C	WB	18°C	CWB	19°C	WB	20°C	CWB	22°C	CWB	24°C	WB
	terriperature	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
	10	2.82	2.45	2.95	2.41	3.06	2.54	3.11	2.51	3.16	2.48	3.26	2.59	3.34	2.52
	12	2.77	2.43	2.90	2.39	3.01	2.52	3.07	2.49	3.12	2.47	3.22	2.58	3.31	2.51
	14	2.71	2.41	2.85	2.37	2.97	2.50	3.03	2.48	3.08	2.45	3.18	2.56	3.28	2.50
	16	2.66	2.38	2.80	2.35	2.92	2.49	2.98	2.46	3.04	2.44	3.15	2.55	3.24	2.49
	18	2.60	2.36	2.74	2.33	2.88	2.47	2.94	2.45	2.99	2.42	3.11	2.54	3.20	2.48
	20	2.55	2.33	2.68	2.30	2.83	2.45	2.89	2.43	2.95	2.40	3.07	2.52	3.17	2.47
	22	2.49	2.31	2.63	2.28	2.78	2.42	2.84	2.41	2.90	2.38	3.02	2.51	3.13	2.45
Hi	24	2.43	2.28	2.57	2.26	2.72	2.40	2.80	2.39	2.85	2.37	2.98	2.49	3.08	2.44
9.9	26	2.37	2.25	2.51	2.23	2.67	2.38	2.74	2.37	2.80	2.35	2.93	2.48	3.04	2.43
(m³/min)	28	2.31	2.19	2.44	2.20	2.61	2.36	2.69	2.35	2.75	2.33	2.89	2.46	3.00	2.41
	30	2.24	2.13	2.38	2.17	2.56	2.34	2.64	2.33	2.70	2.31	2.84	2.44	2.95	2.40
	32	2.18	2.07	2.31	2.15	2.50	2.32	2.58	2.31	2.64	2.29	2.79	2.43	2.90	2.38
	34	2.11	2.00	2.25	2.12	2.44	2.29	2.53	2.29	2.59	2.27	2.74	2.41	2.85	2.37
	35	2.08	1.97	2.21	2.10	2.41	2.28	2.50	2.28	2.56	2.26	2.71	2.40	2.83	2.36
	36	2.04	1.94	2.18	2.07	2.38	2.26	2.47	2.27	2.53	2.25	2.69	2.40	2.80	2.36
	38	1.97	1.87	2.11	2.00	2.32	2.20	2.41	2.24	2.47	2.22	2.63	2.38	2.75	2.34
	39	1.94	1.84	2.07	1.97	2.28	2.17	2.38	2.23	2.44	2.21	2.61	2.37	2.72	2.33

		Heating mo	ode (HC)			(kW)
Air flow	Outdoor air		Indoo	or air tempe	rature	
	temperature	16°CDB	18°CDB	20°CDB	22°CDB	24°CDB
	-15°CWB	1.97	1.93	1.88	1.84	1.80
	-10°CWB	2.23	2.19	2.16	2.10	2.06
	-5°CWB	2.41	2.38	2.33	2.30	2.27
Hi	0°CWB	2.53	2.49	2.45	2.42	2.38
11.3	5°CWB	3.22	3.19	3.17	3.10	3.06
(m³/min)	6°CWB	3.27	3.24	3.20	3.16	3.12
	10°CWB	3.48	3.45	3.42	3.38	3.34
	15°CWB	3.79	3.75	3.73	3.69	3.65
	20°CWB	4.07	4.04	4.02	3.97	3.94

Models SRK35ZS-W -WB, -WT

Cooling mode

(kW)

(kW)

	0.44						lindo	or air t	empera	ature					
Air flow	Outdoor air	21°C	DB	23°0	CDB	26°0	DB	27°C	DB	28°0	CDB	31°0	CDB	33°C	DB
All llow	temperature	14°C	WB	16°C	CWB	18°C	CWB	19°C	WB	20°C	CWB	22°C	CWB	24°C	WB
	temperature	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
	10	3.94	3.19	4.13	3.14	4.28	3.27	4.35	3.22	4.43	3.18	4.56	3.29	4.68	3.20
	12	3.87	3.15	4.06	3.11	4.22	3.24	4.29	3.20	4.37	3.16	4.51	3.27	4.63	3.18
	14	3.80	3.12	3.99	3.07	4.16	3.21	4.24	3.17	4.31	3.14	4.46	3.26	4.59	3.16
	16	3.72	3.08	3.91	3.04	4.09	3.18	4.18	3.15	4.25	3.12	4.40	3.24	4.54	3.15
	18	3.65	3.04	3.84	3.00	4.03	3.16	4.11	3.13	4.19	3.09	4.35	3.21	4.49	3.13
	20	3.57	3.01	3.76	2.97	3.96	3.12	4.05	3.10	4.13	3.06	4.29	3.19	4.43	3.12
	22	3.49	2.96	3.68	2.93	3.89	3.10	3.98	3.07	4.06	3.04	4.23	3.17	4.38	3.10
Hi	24	3.40	2.93	3.59	2.89	3.81	3.07	3.91	3.05	3.99	3.02	4.17	3.15	4.32	3.08
11.3	26	3.32	2.89	3.51	2.86	3.74	3.03	3.84	3.01	3.92	2.98	4.11	3.13	4.26	3.06
(m³/min)	28	3.23	2.84	3.42	2.82	3.66	3.00	3.77	2.99	3.85	2.96	4.04	3.11	4.20	3.04
	30	3.14	2.80	3.33	2.78	3.58	2.97	3.70	2.96	3.78	2.93	3.98	3.08	4.13	3.02
	32	3.05	2.75	3.24	2.74	3.50	2.93	3.62	2.92	3.70	2.90	3.91	3.06	4.06	2.99
	34	2.95	2.71	3.14	2.69	3.41	2.90	3.54	2.89	3.62	2.87	3.84	3.03	4.00	2.97
	35	2.91	2.69	3.10	2.67	3.37	2.89	3.50	2.88	3.58	2.86	3.80	3.02	3.96	2.96
	36	2.86	2.67	3.05	2.65	3.33	2.87	3.46	2.87	3.54	2.84	3.76	3.01	3.92	2.95
	38	2.76	2.62	2.95	2.61	3.24	2.83	3.38	2.84	3.46	2.81	3.69	2.98	3.85	2.93
	39	2.71	2.57	2.90	2.59	3.20	2.81	3.33	2.81	3.42	2.79	3.65	2.97	3.81	2.92

		Heating mo	ode (HC)			(kW)
Air flow	Outdoor air		Indoo	or air temper	rature	
	temperature	16°CDB	18°CDB	20°CDB	22°CDB	24°CDB
	-15°CWB	2.46	2.41	2.35	2.30	2.25
	-10°CWB	2.79	2.74	2.70	2.63	2.58
	-5°CWB	3.02	2.97	2.91	2.88	2.83
Hi	0°CWB	3.16	3.12	3.06	3.02	2.98
12.3	5°CWB	4.03	3.98	3.96	3.88	3.83
(m³/min)	6°CWB	4.09	4.04	4.00	3.95	3.90
	10°CWB	4.35	4.31	4.28	4.22	4.18
	15°CWB	4.73	4.69	4.66	4.61	4.56
	20°CWB	5.09	5.05	5.02	4.96	4.92

Models SRK50ZS-W, -WB, -WT

	0.11						Indo	or air te	empera	ture					
A := 41 =	Outdoor	21°C	DB	23°C	DB	26°C	DB	27°C	DB	28°C	DB	31°C	DB	33°C	DB
Air flow	air temperature	14°C	WB	16°C	WB	18°C	WB	19°C	WB	20°C	WB	22°C	WB	24°C	WB
	temperature	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
	10	5.63	4.25	5.90	4.17	6.11	4.29	6.22	4.23	6.32	4.17	6.51	4.28	6.69	4.14
	12	5.53	4.19	5.80	4.12	6.03	4.25	6.14	4.19	6.25	4.14	6.44	4.25	6.62	4.12
	14	5.43	4.14	5.70	4.07	5.94	4.21	6.05	4.16	6.16	4.10	6.37	4.22	6.55	4.09
	16	5.32	4.08	5.59	4.02	5.85	4.17	5.96	4.12	6.08	4.07	6.29	4.19	6.48	4.07
	18	5.21	4.02	5.48	3.97	5.75	4.13	5.88	4.08	5.99	4.03	6.21	4.16	6.41	4.04
	20	5.10	3.96	5.37	3.92	5.65	4.08	5.78	4.04	5.90	3.99	6.13	4.13	6.33	4.02
	22	4.98	3.90	5.25	3.86	5.55	4.04	5.69	4.00	5.80	3.95	6.05	4.10	6.25	3.99
Hi	24	4.86	3.84	5.14	3.80	5.45	3.99	5.59	3.96	5.71	3.91	5.96	4.07	6.17	3.96
12.1	26	4.74	3.78	5.01	3.74	5.34	3.94	5.49	3.92	5.61	3.87	5.87	4.03	6.08	3.93
(m ³ /min)	28	4.61	3.72	4.89	3.68	5.23	3.89	5.39	3.87	5.50	3.83	5.78	4.00	5.99	3.90
	30	4.49	3.66	4.76	3.62	5.11	3.85	5.28	3.83	5.40	3.79	5.68	3.96	5.90	3.86
	32	4.35	3.59	4.63	3.56	5.00	3.80	5.17	3.78	5.29	3.75	5.58	3.92	5.81	3.83
	34	4.22	3.53	4.49	3.49	4.88	3.74	5.06	3.74	5.18	3.70	5.48	3.88	5.71	3.80
	35	4.15	3.48	4.42	3.46	4.82	3.72	5.00	3.71	5.12	3.68	5.43	3.86	5.66	3.78
	36	4.08	3.45	4.35	3.43	4.76	3.69	4.94	3.69	5.06	3.66	5.37	3.84	5.61	3.76
	38	3.94	3.38	4.21	3.36	4.63	3.64	4.82	3.64	4.94	3.61	5.27	3.81	5.50	3.73
	39	3.87	3.35	4.14	3.33	4.57	3.61	4.76	3.62	4.88	3.59	5.21	3.79	5.45	3.71

		Heating mo	ode (HC)			(kW)
Air flow	Outdoor air		Indoo	or air tempe	rature	
	temperature	16°CDB	18°CDB	20°CDB	22°CDB	24°CDB
	-15°CWB	3.57	3.49	3.41	3.34	3.26
	-10°CWB	4.04	3.97	3.91	3.81	3.73
	-5°CWB	4.37	4.31	4.22	4.18	4.11
Hi	0°CWB	4.59	4.52	4.44	4.39	4.32
13.9	5°CWB	5.84	5.77	5.74	5.63	5.55
(m³/min)	6°CWB	5.94	5.87	5.80	5.73	5.66
	10°CWB	6.31	6.25	6.21	6.12	6.06
	15°CWB	6.86	6.80	6.76	6.68	6.62
1	20°CWB	7.38	7.32	7.28	7.20	7.14

Notes(1) These data show average statuses.

Depending on the system control, there may be ranges where the operation is not conducted continuously.

These data show the case where the operation frequency of a compressor is

fixed.

(2) Capacities are based on the following conditions.

(2) Capacities are abset of the nonwing ordinary Corresponding refrigerant piping length :5m Level difference of Zero. (3) Symbols are as follows. TC: Total cooling capacity (kW) SHC: Sensible heat capacity (kW) HC: Heating capacity (kW)

8. APPLICATION DATA

Installation of indoor unit

- This installation manual deals with an indoor unit installation only. For an outdoor unit installation, refer to page 56.
 - This unit is designed for R32 or R410A. See a label on the outdoor unit to check refrigerant information.

SAFETY PRECAUTIONS

- Before installation, read the "SAFETY PRECAUTIONS" carefully and strictly follow it during the installation. If unusual tion work in order to protect yourself.
 - user according to the user's manual. The precautionary items mentioned below are distinguished into two levels, **AWARNING** and **ACAUTION**.
 - sequences such as death or severe injury.

 CAUTION Indicates a potentially hazardous situation which, if not avoided, can result in personal in-
 - Both mention the important items to protect your health and safety. Therefore, strictly follow them by any means. ury or property damage.

Model SRK20,25,35,50ZS R32/R410A REFRIGERANT USED

RLF012A105

- · Be sure to explain the operating methods as well as the maintenance methods of this equipment to the noise can be heard during the test run, consult the dealer.
- Be sure to keep the installation manual together with user's manual at a place where it is easily accessi ble to the user any time. Moreover, ask the user to hand the manuals to a new user, whenever required.

○ WARNING

 During pump down work, be sure to stop the compressor before closing service valves and removing connecting pipes.
 If the connecting pipes are removed when the compressor is in operation and operation valves are open, air can be sucked into the refrigerant circuit which can cause anomalous high pressure resulting in burst or personal injury. In the event of refrigerant leakage during installation, be sure to ventilate the

if the refrigerant comes into contact with naked flames, poisonous gases will be produced working area properly

Electrical work must be carried out by the qualified electrician, strictly in accordance with national or regional electricity regulations.

Incorrect installation can cause electric shock, fire or personal injury.

• Make sure that earth leakage breaker and circuit breaker of appropriate ca-

Circuit breaker should be able to disconnect all poles under over current. Absence of appropriate breakers can cause electric shock, personal injury or property damage pacities are installed.

Be sure to switch off the power source in the event of installation, mainteif the power source is not switched off, there is a risk of electric shock, unit failure or personal injury nance or service.

Be sure to tighten the cables securely in terminal block and relieve the cables properly to prevent overloading the terminal blocks.

improper power cable or power plug can cause fire or electric shock due to poor connection, insuficient insulation or over-current other power plugs.

Do not perform any change in protective device or its setup condition yourself

Changing protective device specifications can cause electric shock, fire or burst.

• Be sure to clamp the cables properly so that they do not touch any internal component of the unit.

f cables touch any internal component, it can cause overheating and fire. If air enters the refrigerant circuit, the pressure in the refrigerant circuit will become too high, which • Be sure to install service cover property.

Improper installation can cause electric shock or fire due to intrusion of dust or water

Using improper cables can cause electric leak or fire.

This appliance must be connected to main power source by means of a cir- Be sure to use the prescribed power and connecting cables for electrical work. cuit breaker or switch with a contact separation of at least 3mm

Using improper plug can cause electric shock or fire.

• Be sure to connect the power source cable with power source properly. Improper connection can cause intrusion of dust or water resulting in electric shock or fire. open, air can be sucked into the refrigerant circuit which can cause anomalous high pressure result-If the compressor is operated when connecting pipes are not connected and service valves are

- Be sure to use only for residential purpose. If this unit is installed in inferior environment such as machine shop, vehicle (like ship), warehouse,
- Installation must be carried out by the qualified installer completely in accordance with the installation manual
 - installation by non qualified person or incorrect installation can cause serious troubles such as water leak, electric shock, fire and personal injury
 - Be sure to wear protective goggles and gloves while performing installation work.
- Use the original accessories and the specified components for the installation. Improper safety measures can result in personal inju
- Using parts other than those prescribed may cause water leak, electric shock, fire and personal injury. Do not install the unit near the location where leakage of flammable gases can occur.
- If leaked gases accumulate around the unit, it can cause fire resulting in property damage and personal injury.

 When installing the unit in small rooms, make sure that refrigerant density does not exceed the limit (Reference: ISO5149) in the event of leakage. If refrigerant density exceeds the limit, consult the dealer and install the ventilation system. Otherwise lack of oxygen can occur resulting in serious accident
 - Install the unit in a location where unit will remain stable, horizontal and free of any vibration transmission.
- Do not run the unit with removed panels or protections.

 Loose connections or cable mountings can cause anomalous heat production or fire.

 Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to Do not process, splice or modify the power cable, or share the socket with Unsuitable installation location can cause the unit to fall resulting in material damage and personal injury. Do not run the unit with removed panels or protections.
 - This unit is designed specifically for R32 or R410A.
 Using any other refrigerant can cause unit failure and personal injury. entrapment, burn or electric shock
 - - Do not vent R32 or R410A into atmosphere.
- R32 is a fluorinated greenhouse gas with a Global Warming Potential(GWP)=675. R410A is a fluorinated greenhouse gas with a Global Warming Potential(GWP)=2088.
- Make sure that no air enters the refrigerant circuit when the unit is installed and removed
- can cause burst and personal injury.

 Be sure to use the prescribed pipes, flare nuts and tools for R32 or R410A.
 Using existing parts (for R22 or R407C) can cause refrigerant circuit burst resulting in unit failure and Be sure to connect both liquid and gas connecting pipes properly before oppersonal injury
- erating the compressor.

 Improper electrical work can cause unit failure or personal injury.

 Lot open the liquid and gas service valves before completing piping When plugging this unit, a plug conforming to the standard IEC60884-1 must be work, and evacuation.
- ing in burst or personal injury.

 Be sure to tighten the flare nuts to specified torque using the torque wrench.

 Tightening flare nuts with excess torque can cause burst and refrigerant leakage after a long period.

Take care when carrying the unit by hand.

If the unit weight is more than 20kg, it must be carried by two or more persons

Do not carry the unit by the plastic straps. Always use the carry handle.

Do not install the outdoor unit in a location where insects and small animals can inhabit.

· If the outdoor unit is installed at height, make sure that there is enough space Insects and small animals can enter the electrical parts and cause damage resulting in fire or personal injury. Instruct the user to keep the surroundings clean.

Insufficient space can result in personal injury due to falling from the height for installation, maintenance and service.

· Do not install the unit near the location where neighbours are bothered by noise or air generating from the unit.

· Do not install in the locations where unit is directly exposed to corrosive gases (like sulphide gas, chloride gas), sea breeze or salty atmosphere. It can affect surrounding environment and cause a claim.

It can cause corrosion of heat exchanger and damage to plastic parts.

Unject may rall causing property damage or personial injury.

Do not install the unit close to the equipments that generate electromagnetic • Do not touch the aluminum fin of the outdoor unit. waves and/or high-harmonic waves.

Equipment such as inverters, standby generators, medical high frequency equipments and telecom-The system can also affect medical equipment and telecommunication equipment, and obstruct its munication equipments can affect the system, and cause malfunctions and breakdowns. unction or cause jamming.

Do not install the unit in the locations where:

There are heat sources nearby.

Unit is directly exposed to rain or sunlight.
 There is any obstacle which can prevent smooth air circulation from inlet and outlet side of the unit.
 Unit is directly exposed to oil mist and steam such as kitchen.

Chemical substances like ammonia (organic fertilizer), calcium chloride (snow melting agent) and acid (sulfurous acid etc.), which can harm the unit, will generate or accumulate.

Drain water can not be discharged properly.
TV set or radio receiver is placed within 1m.

Height above sea level is more than 1000m.

It can cause performance degradation, corrosion and damage of components, unit malfunction and fire. · Dispose of all packing materials properly.

Keep the polybag away from children to avoid the risk of suffocation

Packing materials contain nails and wood which can cause personal injury.

Do not put anything on the outdoor unit

Aluminium fin temperature is high during heating operation. Touching fin can cause burn.

 Do not touch any refrigerant pipe with your hands when the system is in operation. During operation the refrigerant pipes become extremely hot or extremely cold depending on the operating condition. Touching pipes can cause personal injury like burn (hot/cold).

· Install isolator or disconnect switch on the power source wiring in accor-The isolator should be locked in OFF state in accordance with EN60204-1. dance with the local codes and regulations.

1. ACCESSORIES AND TOOLS

L	Standard	accessorie	ins) s	plie	Standard accessories (supplied with indoor unit)			Locally procured parts	
		6				Ç		(a) Sleeve (1pc)	Plus hea
Ξ	Installation board		1pc	(9)	1pc (6) Batteries [R03 (AAA, Micro) 1.5V]	E.	2pcs	(b) Sealing plate (1pc)	Knife
				1		>		(c) Inclination plate (1pc)	
(5)	(2) Remote control		1pc	(2)	1pc (7) Air-cleaning filters		2pcs	(d) Putty	Saw
								(e) Connecting cable	Tape me
<u>ල</u>	(3) Remote control holder		1pc	(8)	1pc (8) Filter holders	Zpcs Spcs	2pcs	(f) Drain hose (extension hose)	Torque
		}						Pining cover	_
(4)	(4) Tapping screws	d	Spcs	(6)	5pcs (9) Insulation (#486 50 X 100 t3)		100	(g) (for insulation of connection piping)	Plier
	(for installation board ø4 X 25mm)	}	1		(Clamp and screw (for finishing	
(5)	Wood screws		Suce					(h) work)	Pipe cut
2	(for remote control holder ø3.5 X 16mm)	b	2703					(i) Electrical tape	

Tools for	Tools for installation Work
Plus headed driver	Hole core drill (65mm in diameter)
Knife	Wrench key (Hexagon) [4mm]
Saw	Flaring tool set*
Tape measure	Gas leak detector*
Torque wrench (14.0-62.0N·m (1.4-6.2kgf·m))	Pipe bender
Plier	Gauge for projection adjustment
Pipe cutter	conventional flare tool)
* Design	* Designed specifically for R32 or R410A

Improper adjustment of the installation board can cause water leakage

2. SELECTING INSTALLATION LOCATION

After getting customer's approval, select installation location according to following guidelines.

1. Indoor unit

Where there is no obstruction to the air flow and where the cooled and heated air can be evenly
distributed.

- A solid place where the unit or the wall will not vibrate.
 A place where there will be enough space for servicing. (Where space mentioned on the right side
- can be secured.)

 Where it is easy to conduct wiring and piping work.

 A place where unit is not directly exposed to sunlight or street light.

 A place where it can be easily drained.

 A place separated at least 1m away from the television or the radio. (To prevent interference to images and sounds.

95

Be sure that the flap of outlet should not touch any obstacles.

(a) Sleeve

Remote control

Remote control holder

Wood screws

Obstacle such

Installation example

10 cm minimum from the ceiling

Indoor unit

10 cm minimum from the wall

Installation board

5 cm minimum from the wall


A place where this unit is not affected by the high frequency equipment or electric equipment.
Avoid installing this unit in place where there is much oil mist.
A place where there is no electric equipment or household.
Install the indoor unit on the wall where the height from the floor to the bottom of the unit is more than


- 2. Remote control
 A place where the air-conditioner can receive the signal surely during operating the remote control.
 A place where it is not affected by the TV, radio etc.
 Do not place where it is exposed to direct sunlight or near heat devices such as a stove.


180 cm minimum from the floor

3. INSTALLING INSTALLATION BOARD

- Installation board should be installed on the wall which can support the weight of the indoor unit.
 Adjustment of the installation board in the horizontal direction is to be conducted with five screws in a temporary lightened state.
 With the standard hole as a center, adjust the board and level it.











4. DRILLING HOLE AND FIXTURE OF SLEEVE


When drilling the wall that contains a metal lath, wire lath or metal plate, be sure to use sealing plate, sleeve and inclination plate (Locally procured parts)















(4) After piping work, seal the hole in the wall

Completely seal the hole in the wall with putty. If not sealed properly, dust, insects, small animals, and highly humid air may enter the room from outside, which could result in fire or other hazards.

△ CAUTION


Completely seal the hole in the wall with putty. If not sealed properly, furniture and other fixtures may be damaged by water leakage or condensation.

5. ELECTRICAL WIRING WORK

- 2. Connecting cable

 (1) Open the air inlet panel.
 (2) Remove the lid.
 (3) Remove the cable clamp.
 (4) Connect the connecting wires to the terminal block.
 (5) Fix the connecting cable by cable clamp.
 (6) Fix the lid.
 (7) Close the air inlet panel. · Before installation, make sure that the power source complies with the air-conditioner's power speci-
 - · Carry out electrical wiring work according to following guidelines.
- 1. Preparing cable
- (1) Selecting cable Selecting cable in accordance with the specifications mentioned below. Select the connecting cable in accordance with 60245 IEC57 4-core* 1.5mm² conformed with 60245 IEC57
 - (2) Arrange each wire length as shown below. Make sure that each wire is stripped 10mm from the end.






Earth wire








Take care not to confuse the terminal numbers for indoor and outdoor connections

NOTE



△ WARNING

Incorrect wiring connection can cause malfunction or fire.



9. CONNECTING PIPING WORK

1. Preparation of connecting pipe

1.1. Selecting connecting pipe

Select connecting pipe according to the following table.

	Model SRK20/25/35	Model SRK50
Gas pipe	ø9.52	ø12.7
Liquid pipe	ø6.35	ø6.35


Pipe wall thickness must be greater than or equal to 0.8 mm.
 Pipe material must be O-type (Phosphorus deoxidized seamless copper pipe ICS 23.040.15, ICS 77.150.30).

1.2. Cutting connecting pipe

- Cut the connecting pipe to the required length with pipe cutter.
 Hold the pipe downward and remove the burns. Make sure that no foreign material enters the pipe.
 Cover the connecting pipe ends with the tape.

2. Piping work

- (1) Take out flare nuts from the operation valves of indoor unit and engage them onto connecting pipes. (2) Flare the pipes according to table and figure shown below. Although it is recommended to use the flaring tools designed specifically for R32 or R410A, conventional flaring tools can also be used by adjusting the dimension B with a flare adjustment Flare the pipes according to table and figure shown below. Flare dimensions for R32 are different from those for conventional refrigerant. 2.1. Flaring pipe



R32 or R410A | Conventional B [Rigid (clutch) type] Copper pipe outer diameter

Liquid side (Do not turn)

2.2 Connecting pipes

- Connect pipes on both liquid and gas sides.
 Tighten nuts to specified torque shown in the table below.
- Tightening torque (N·m) 14-18 34-42 Operation valve size (mm) ø6.35 (1/4") ø9.52 (3/8")


49-61 ø12.7 (1/2")

△ CAUTION


Do not apply refrigerating machine oil to the flared surface. It can cause refrigerant leakage.
 Do not apply excess torque to the flared nuts. The flared nuts may crack resulting in refrigerant leakage.

- Heating and condensation prevention
 Dress the connecting pipes (both liquid and gas pipes) with insulation to prevent it from heating and Use the heat insulating material which can withstand 120°C or higher temperature. Make sure that insu
 - lation is wrapped tightly around the pipes and no gap is left between them.
- (2) Wrap the refrigerant pipings of indoor unit with indoor unit heat insulation using tape.
 (3) Cover the flare-connected joints (indoor side) with the indoor unit heat insulation and wrap it with an insulation pad (standard accessory provided with indoor unit).
 - (4) Connecting cable (4) Wrap the connecting pipes, connecting cable and drain hose with the tape

(2)



Q



3as pipe

Locations where relative humidity exceeds 70%, both liquid and gas pipes need to be dressed with 20mm or thicker heat insulation materials.

Improper insulation can cause condensate(water) formation during cooling operation. **○ CAUTION**

- Condensate can leak or drip causing damage to household property.

 Poor heat insulating capacity can cause pipe outer surface to reach high temperature during heating operation. It can cause cable deterioration and personal injury. Finishing work
 - (1) Make sure that the exterior portion of connecting pipes, connecting cable and drain hose is wrapped properly with tape. Shape the connecting pipes to match with the contours of the pipe assembly route.

 (2) Fix the pipe assembly with the wall using clamps and screws. Pipe assembly should be anchored every 1.5m or less to isolate the vibration.

1.0-1.5

0-0.5


(3) Install the service cover securely. Water may enter the unit if service cover not installed properly, resulting in unit malfunction and failure.

Pipe assembly (h)Clamp

o



must/shall be installed outdoors.



Flared joint outside Wall To avoid the risk of fire or explosion, the flared connection

allowed indoors.

Reusable mechanical connectors and flared joints are not

△ CAUTION

Make sure that the connecting pipes do not touch the components within the unit. If pipes touch the internal components, it may generate abnormal sounds and/or vibrations.


10. HOW TO OPEN, CLOSE, REMOVE AND INSTALL THE AIR INLET PANEL

Pull the air inlet panel at both ends of lower part and release latches, then pull up the panel until you feel resistance.

(The panel stops at approx. 70° open position)

Hold the panel at both ends of lower part, lower it downward slowly, then push it slightly until the 3. Removing
Open the panel by 90° (as shown in the right illustration) and then pull it forward. latch works

panel from the position shown in right illustra-tion, hold the panel at both ends of lower part, lower it downward slowly, then push it slightly Insert the panel arm into the slot on the front until the latch works. 4. Installing



11. HOW TO REMOVE AND INSTALL THE BOTTOM AND FRONT PANEL

Front panel

1. Bottom panel

Removing
 Screws (in the cap).
 Remove the 2 screws (in the cap).
 Remove the 2 hocks of left and right side and then bottom panel can be removed.

1.2. Installing

(1) Install the 2 hooks of left and right side. (2) Secure the bottom panel with the 2 screws

(in the cap).

2.1. Removing (1) Remove the air inlet panel, the air filters and the 2. Front panel

Bottom panel

Screw (in the cap)

bottom panel

- (2) Remove the 2 screws.(3) Remove the 4 upper latches and then front
 - panel can be removed. 2.2. Installing
- (1) Cover the unit with the front panel and fix 4

upper latches. (2) Secure the front panel with the 2 screws. (3) Install the bottom panel, the air inlet panel and the air filters.

13. TERMINAL CONNECTION FOR AN INTERFACE

To install wired remote control, superlink etc., interface kit is needed.

Control cover


Indoor unit PCB

bottom panel and front panel. (2) Remove the control cover. (1) Remove the air inlet panel,


connect to the respective (Remove the screw.) (3) There is a terminal

(respectively marked with CNS) for the indoor control board. While connecting an interface, connection kit SC-BIKN-E and SC-BIKN2-E" and fasten the connection harness supplied with an optional "Interface terminal securely with the

For more details, refer to the user's manual of "Interface connection kit SC-BIKN-E and SC-BIKN2-E". the kit.



clamp and screw supplied with connection harness onto the indoor control box with the



Installing remote control holder (1) Select the place where the unit can receive 12. INSTALLING REMOTE CONTROI

signals. (2) Fix the holder to pillar or wall with wood

screws.

Mount the batteries

(1) Slide and take out the cover of backside.


(2) Mount the batteries [R03 (AAA, Micro), x2 pieces] in the body properly.

(Fit he poles with the indication marks + & -)

(3) Set the cover again.

NOTE

Do not use new and old batteries together.
 In case the unit is not operated for a long time, take out the batteries




14. INSTALLING TWO AIR-CONDITIONERS IN THE SAME ROOM

In case two air-conditioners are installed in the same room, apply this setting so that one unit can be operated with only one remote control.

Setting one remote control

- (1) Slide and take out the cover and batteries. (2) Cut the switching line next to the battery
 - with wire cutters.

 (3) Set the batteries and cover again.



Setting one indoor unit

- (1) Turn off the power source and turn it on after
- on the remote control that was set according to the procedure described on the left side. (3) Check that the reception buzzer sound "Peep" is emitted from the indoor unit. Since (2) Send the signal by pressing the ACL switch
 - the signal is sent about 6 seconds after the ACL switch is pressed, point the remote control to the indoor unit for a while.

NOTE

If no reception buzzer is emitted, restart the setting from the beginning.



16. INSTALLATION CHECK AND TEST RUN

After finishing the installation work, check the following points again before turning on the power. Conduct a test run and ensure that the unit operates properly. At the same time, explain to the customer how to use the unit and how to take care of the unit following the user's manual. Indoor unit receives signal of remote control. **Test run** Check following points during test run. Air-conditioning operation is normal. There is no abnormal noise Water drains out smoothly.

Display of remote control is normal.

Explain the operating and maintenance methods to the user according to the user's manual. Keep this installation manual together with user's manual. After test run

15. PUMP DOWN WORK

For the environmental protection, be sure to pump down when relocating or disposing of the unit. Pump down is the method of recovering refrigerant from the indoor unit to the outdoor unit before the connecting pipes are removed from the unit. When pump down is carried out, forced cooling operation is needed.

Forced cooling operation (1) Turn off the power source and turn it on

- again after 1 miniute.
- (2) Press the ON/OFF button continuously for at least 5 seconds. Then operation will start.

For the detail of pump down, refer to the installation manual of outdoor unit.

	/ Unit ON/OFF button

NOTE

During restart or change in operation mode, the unit will not start operating for approximately 3 minutes. This is to protect the unit and it is not malfunction.

Power source voltage complies with the rated voltage of Indoor and outdoor side pipe joints have been insulated. Power cable and connecting cable are securely fixed to Earth leakage breaker and circuit breaker are installed No gas leaks from the joints of the service valves. Both liquid and gas service valves are fully open. Hole on the wall is completely sealed with putty. Drain hose and cap are installed properly. Before test run, check following points.

(2) Installation of outdoor unit

RWC012A068

Model SRC20,25,35,50ZS-W **R32 REFRIGERANT USED**

· This installation manual deals with an outdoor unit installation only. For an indoor unit installation, refer to page 48.

SAFETY PRECAUTIONS

 Before installation, read the "SAFETY PRECAUTIONS" carefully and strictly follow it during the einstallation on the operation problem on the equipment after completing the installation. If unusual noise can be heard during the test run, consult the dealer.
 The precautionary items mentioned below are distinguished into two levels, AWARNING indicates a potentially hazardous situation which, if not avoided, can result in serious consequences such as death or severe injury.
 CAUTION Indicates a potentially hazardous situation which, if not avoided, can result in personal information of the properties of the dealer.
 Be sure to explain the operating methods as well as the maintenance methods of this equipment to the user according to the user's manual.
 Be sure to explain the operating methods as well as the maintenance methods of this equipment to the user according to the user's manual.
 Be sure to explain the operating methods as well as the maintenance methods of this equipment to the user according to the user's manual.
 Be sure to explain the operating methods as well as the maintenance methods of this equipment to the user according to the user's manual.
 Be sure to explain the operating methods as well as the maintenance methods of this equipment to the user as the maintenance method of this equipment at the operating methods as well as the maintenance methods of this equipment to the user as the maintenance methods of this equipment to the user as the maintenance method of this equipment to the user as the maintenance method of this equipment to the user as the maintenance method of the maintenance method of the user as the maintenance method of the maintenance method of the maintenance method of the user as the maintenance method of the maintenance method of the user as the maintenance method of the maintena sequences such as death or severe injury.

A CAUTION Indicates a potentially hazardous situation which, if not avoided, can result in personal in-

jury or property damage.

Both mention the important items to protect your health and safety. Therefore, strictly follow them by any means.

- Before installation, read the "SAFETY PRECAUTIONS" carefully and strictly follow it during the installa- Be sure to confirm no operation problem on the equipment after completing the installation. If unusual

- Be sure to use only for residential purpose.
 If this unit is installed in inferior environment such as machine shop, vehicle (like ship), warehouse, etc., it can malfunction.
- Installation must be carried out by the qualified installer completely in accor-

- Installation must be carried out by the qualified installer completely in accordance with the installation manual.
 Installation by non qualified person or incorrect installation can cause serious troubles such as water leak, electric shock, fire and personal injury.
 Be sure to wear protective goggles and gloves while performing installation work. Improper safety measures can result in personal injury.
 Use the original accessories and the specified components for the installation.
 Using parts other than those prescribed may cause water leak, electric shock, fire and personal injury.
 Do not install the unit near the location where leakage of flammable gases can occur. If leaked gases accumulate around the unit, it can cause fire resulting in property damage and personal injury.
 When installing the unit in small rooms, make sure that refrigerant density
- sonal injury.

 When installing the unit in small rooms, make sure that refrigerant density does not exceed the limit (Reference: ISO5149) in the event of leakage. If refrigerant density exceeds the limit, consult the dealer and install the ventilation system. Otherwise lack of oxygen can occur resulting in serious accident. Install the unit in a location where unit will remain stable, horizontal and free of any vibration transmission.

 Unsuitable installation location can cause the unit to fall resulting in material damage and personal injury.

- Do not run the unit with removed panels or protections.

 Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shock.

- entrapment, burn or electric shock.

 This unit is designed specifically for R32.

 Using any other refrigerant can cause unit failure and personal injury.

 Do not vent R32 into atmosphere.

 R32 is a fluorinated greenhouse gas with a Global Warming Potential(GWP)=675.

 Make sure that no air enters the refrigerant circuit when the unit is installed and removed.

 If air enters the refrigerant circuit, the pressure in the refrigerant circuit will become too high, which
- can cause burst and personal injury.

 Be sure to use the prescribed pipes, flare nuts and tools for R32 or R410A.

 Using existing parts (for R22 or R407C) can cause refrigerant circuit burst resulting in unit failure and personal injury.

 Be sure to connect both liquid and gas connecting pipes properly before op-
- Be sure to connect both indust and gas service valves before completing piping mork, and evacuation.

 If the compressor is operated when connecting pipes are not connected and service valves are open, air can be sucked into the refrigerant circuit which can cause anomalous high pressure result-
- Be sure to tighten the flare nuts to specified torque using the torque wrench.
 Tightening flare nuts with excess torque can cause burst and refrigerant leakage after a long period.

- During pump down work, be sure to stop the compressor before closing service valves and removing connecting pipes. If the connecting pipes are removed when the compressor is in operation and service valves are open, air can be sucked into the refrigerant circuit which can cause anomalous high pressure result-
- ing in burst or personal injury. In the event of refrigerant leakage during installation, be sure to ventilate the
- working area properly.

 If the refrigerant comes into contact with naked flames, poisonous gases will be produced
- Electrical work must be carried out by the qualified electrician, strictly in accordance with national or regional electricity regulations. Incorrect installation can cause electric shock, fire or personal injury.

 Make sure that earth leakage breaker and circuit breaker of appropriate ca-
- pacities are installed.

 Circuit breaker should be able to disconnect all poles under over current. Absence of appropriate breakers can cause electric shock, personal injury or property damage.

 Be sure to switch off the power source in the event of installation, mainte-

- nance or service.

 If the power source in the event of installation, maintenance or service.

 If the power source is not switched off, there is a risk of electric shock, unit failure or personal injury.

 Be sure to tighten the cables securely in terminal block and relieve the cables properly to prevent overloading the terminal blocks.

 Loose connections or cable mountings can cause anomalous heat production or fire.

 Do not process, splice or modify the power cable, or share the socket with

- **other power plugs.**Improper power cable or power plug can cause fire or electric shock due to poor connection, insufficient insulation or over-current.
- ficient insulation or over-current.

 Do not perform any change in protective device or its setup condition yourself.

 Changing protective device specifications can cause electric shock, fire or burst.

 Be sure to clamp the cables properly so that they do not touch any internal component of the unit.

 If cables touch any internal component, it can cause overheating and fire.

 Be sure to install service cover properly.

 Improper installation can cause electric shock or fire due to intrusion of dust or water.

- Improper installation can cause electric shock or fire due to influsion of use of water.

 Be sure to use the prescribed power and connecting cables for electrical work. Using improper cables can cause electric leak or fire.

 This appliance must be connected to main power source by means of a circuit breaker or switch with a contact separation of at least 3mm. Improper electrical work can cause unit failure or personal injury.

 When plugging this unit, a plug conforming to the standard IEC60884-1 must be used.
- Using improper plug can cause electric shock or fire.
- Be sure to connect the power source cable with power source properly.

 Improper connection can cause intrusion of dust or water resulting in electric shock or fire.

⚠ CAUTION

- Take care when carrying the unit by hand.

 If the unit weight is more than 20kg, it must be carried by two or more persons.

 Do not carry the unit by the plastic straps. Always use the carry handle.

 Do not install the outdoor unit in a location where insects and small animals
- Insects and small animals can enter the electrical parts and cause damage resulting in fire or per-
- Insects and small animals can relief the electrical parts and cause damage resulting in the or personal injury. Instruct the user to keep the surroundings clean.

 If the outdoor unit is installed at height, make sure that there is enough space for installation, maintenance and service.

 Insufficient space can result in personal injury due to falling from the height.

 Do not install the unit near the location where neighbours are bothered by noise or air generating from the unit.

- noise or air generating from the unit. It can affect surrounding environment and cause a claim. Do not install in the locations where unit is directly exposed to corrosive gases (like sulphide gas, chloride gas), sea breeze or salty atmosphere. It can cause corrosion of heat exchanger and damage to plastic parts. Do not install the unit close to the equipments that generate electromagnetic waves and/or high-harmonic waves.
- Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns.
- The system can also affect medical equipment and telecommunication equipment, and obstruct its function or cause jamming

- Do not install the unit in the locations where:

 - Do not install the unit in the locations where:

 There are heat sources nearby.

 Unit is directly exposed to rain or sunlight.

 There is any obstacle which can prevent smooth air circulation from inlet and outlet side of the unit.

 Unit is directly exposed to oil mist and steam such as kitchen.

 Chemical substances like ammonia (organic fertilizer), calcium chloride (snow melting agent) and acid (sulfurous acid etc.), which can harm the unit, will generate or accumulate.

 Drain water can not be discharged properly.

 TV set or radio receiver is placed within 1m.

 Height above sea level is more than 1000m.

- Height above sea level is more than 1000m.
 It can cause performance degradation, corrosion and damage of components, unit malfunction and fire.
 Dispose of all packing materials properly.
 Packing materials contain nails and wood which can cause personal injury.
 - Keep the polybag away from children to avoid the risk of suffocation.

- Reep the polypag away from children to avoid the risk of sufficiation.

 Do not put anything on the outdoor unit.
 Object may fall causing property damage or personal injury.

 Do not touch the aluminum fin of the outdoor unit.
 Aluminium fin temperature is high during heating operation. Touching fin can cause burn.

 Do not touch any refrigerant pipe with your hands when the system is in operation.
 During operation the refrigerant pipes become extremely hot or extremely cold depending on the operating condition. Touching pipes can cause personal injury like burn (hot/cold).
 Install isolator or disconnect switch on the power source wiring in accordance with the local codes and regulations.

 The isolator should be locked in OFF state in accordance with EN60204-1.

1. ACCESSORIES AND TOOLS Standard accessories Q'ty Locally procured parts Tools for installation work (Supplied with outdoor unit Anchor bolt(M10-M12)×4 pcs Plus headed driver Vacuum pump (1) Drain grommet @ 1 (b) Putty Knife Torque wrench [14.0-62.0N+m(1.4-6.2kgf+m)] Gauge manifold (2) Drain elbow 1 Electrical tape Wrench key (Hexagon) [4mm] Charge hose Vacuum pump adapter* (Anti-reverse flow type) Connecting pipe Tape measure Flaring tool set ' Connecting cable ower cable (g) Clamp and screw (for finishing work) *Designed specifically for R32 or R410A

2. OUTDOOR UNIT INSTALLATION

Note as a unit designed for R32

- Do not use any refrigerant other than R32. R32 will rise to pressure about 1.6 times higher than that of a conventional refrigerant. A cylinder containing R32 has a light blue indication mark on the top.
 Do not use a charge cylinder. The use of a charge cylinder will cause the refrigerant composition to change, which results in performance degradation.
- In charging refrigerant, always take it out from a cylinder in the liquid phase
- All indoor units must be models designed exclusively for R32. Check connectable indoor unit models in a catalog, etc. (A wrong indoor unit, if connected into the system, will impair proper system operation)

1. Haulage

- Always carry or move the unit with two or more persons.
 The right hand side of the unit as viewed from the front (outlet side) is

A person carrying the right hand side must take care of this fact. A person carrying the left hand side must hold the handle provided on the front panel of the unit with his right hand and the corner column section of the unit with his left hand.



⚠ CAUTION

When a unit is hauled, take care of its gravity center position which is shifted towards right hand side If the unit is not hauled properly, it can go off balance and fall resulting in serious injury.

2. Selecting the installation location

ole installation location where

- Unit will be stable, horizontal and free of any vibration transmission.
 There is no obstacle which can prevent smooth air circulation from inlet and outlet side of the unit.
 There is enough space for service and maintenance of unit.
- Neighbours are not bothered by noise or air generating from the unit.
 Outlet air of the unit does not blow directly to animals or plants.
 Drain water can be discharged properly.
 There is no risk of flammable gas leakage.

- There are no other heat sources nearby.

- Unit is not directly exposed to rain or sunlight.
 Unit is not directly exposed to oil mist and steam.
 Chemical substances like ammonia (organic fertilizer), calcium chloride (snow melting agent) and acid (sulfurous acid etc.), which can harm the unit, will not generate or accumulate
- Unit is not directly exposed to corrosive gases (like sulphide gas, chloride gas), sea breeze or salty at-
- mosphere.

 No TV set or radio receiver is placed within 1m.


- Unit is not affected by electromagnetic waves and/or high-harmonic waves generated by other equipments.
 Strong wind does not blow against the unit outlet.
 Heavy snowfalls do not occur (If installed, provide proper protection to avoid snow accumulation).


NOTE

If the unit is installed in the area where there is a possibility of strong wind or snow accumulation, the following measures are required.

(1) Location of strong wind

· Place the unit with its outlet side facing the wall.








(2) Location of snow accumulation


- · Install the unit on the base so that the bottom is higher than snow cover surface.

 Install the unit under eaves or provide the roof on



3. Installation space

There must be 1 meter or larger space between the unit and the wall in at least 1 of the 4 sides. Walls surrounding the unit from 4 sides is not acceptable. The wall height on the outlet side should be 1200 mm or less. Refer to the following figure and table for details.



	Installation space (mm)
L1	280 or more
L2	100 or more
L3	80 or more
L4	250 or more

NOTE

When more than one unit are installed side by side, provide a 250mm or wider interval between them as a service space.

⚠ CAUTION


When more than one unit are installed in parallel directions, provide sufficient inlet space so that short-circuiting may not occur.

4. Drain piping work (If necessary)

Carry out drain piping work by using a drain elbow and a drain grommet supplied separately as accessories if condensed water needs to be drained out.

(1) Install drain elbow and drain grommet.

(2) Seal around the drain elbow and drain grommet with putty or adequate caulking material.




△ CAUTION

Do not use drain elbow and drain grommet if there is a possibility to have several consecutive days of sub zero temperature. (There is a risk of drain water freezing inside and blocking the drain.)

5. Installation

- Install the unit on a flat level base.

 While installing the unit, keep space and fix the unit's legs with 4 anchor bolts as shown in the figure below. The protrusion of an anchor bolt from the foundation surface must be kept within 15mm



△ CAUTION

- · Install the unit properly so that it does not fall over during earthquake, strong wind, etc
- · Make sure that unit is installed on a flat level base. Installing unit on uneven base may result in unit

3. PREPARATION FOR WORK 1. Removing service cover 2. Removing terminal cover ve the screw. Slide service cover downwards and remove it. Remove the screw and take out terminal cover. (For SRC50, terminal cover is attached to service cover. Therefore, there is no need to remove terminal cover separately.) <SRC20/25/35> <SRC50> Terminal cover


4. CONNECTING PIPING WORK

1. Restrictions on unit installation

Abide by the following restrictions on unit installation.

Improper installation can cause compressor failure or performance degradation

	Dimensional restrictions	
	Model SRC20/25/35	Model SRC50
Connecting pipe length(L)	20m or less	25m or less
Elevation difference between indoor and outdoor units(H)*	10m or less	15m or less



Outdoor unit installation position can be higher as well as lower than the indoor unit installation position.

2. Preparation of connecting pipe

2.1. Selecting connecting pipe

Select connecting pipe according to the following table

	Model SRC20/25/35	Model SRC50	
Gas pipe	ø9.52	ø12.7	
Liquid pipe	ø6.35	ø6.35	

Pipe wall thickness must be greater than or equal to 0.8 mm.
Pipe material must be O-type (Phosphorus deoxidized seamless copper pipe ICS 23.040.15, ICS 77.150.30).

NOTE


If it is required to reuse the existing connecting pipe system, refer to 5. UTILIZATION OF EXISTING PIPE.

2.2. Cutting connecting pipe

- Cut the connecting pipe to the required length with pipe cutter.
 Hold the pipe downward and remove the burrs. Make sure that no foreign material enters the pipe.
 Cover the connecting pipe ends with the tape.

3. Piping work

Check that both liquid and gas service valves are fully closed. Carry out the piping work with service valves fully closed



3.1. Flaring pipe

3.1. Flaring pipe (1) Take out flare nuts from the service valves of outdoor unit and engage them onto connecting pipes. (2) Flare the pipes according to table and figure shown below. Flare dimensions for R32 are different from those for conventional refrigerant. Although it is recommended to use the flaring tools designed specifically for R32 or R410A, conventional flaring tools can also be used by adjusting the dimension B with a flare adjustment gauge.



ω.	Copper pipe	B [Rigid (clutch) type]		
	outer diameter	R32 or R410A	Conventional	
	ø6.35			
	ø9.52	0-0.5	1.0-1.5	
J	ø12.7			
		outer diameter ø6.35 ø9.52	outer diameter R32 or R410A @6.35 @9.52 0-0.5	

3.2. Connecting pipes
(1) Connect pipes on both liquid and gas sides.
(2) Tighten nuts to specified torque shown in the table below.


Service valve size (mm)	Tightening torque (N·m)
ø6.35 (1/4")	14-18
ø9.52 (3/8")	34-42
ø12.7 (1/2")	49-61



A CAUTION

Do not apply refrigerating machine oil to the flared surface. It can cause refrigerant leakage Do not apply excess torque to the flared nuts. The flared nuts may crack resulting in refrigerant leakage.

5. UTILIZATION OF EXISTING PIPE



4. Evacuation

- (1) Connect vacuum pump to gauge manifold. Connect charge hose of gauge manifold to service port of outdoor unit.
- (2) Run the vacuum pump for at least one hour after the vacuum gauge shows -0.1MPa (-76cm Hg).
- (2) Run the vacuum pump for at least one hour after the vacuum gauge shows -0.1MPa (-76cm Hg).
 (3) Confirm that the vacuum gauge indicator does not rise even if the system is left for 15 minutes or more. Vacuum gauge indicator will rise if the system has moisture left inside or has a leakage point. Check the system for the leakage point. If leakage point is found, repair it and return to (1) again.
 (4) Close the Handle Lo and stop the vacuum pump.
 Keep this state for a few minutes to make sure that the compound pressure gauge pointer does not such process.
- swing back
- (5) Remove valve caps from liquid service valve and gas operation valve.
 (6) Turn the liquid service valve's rod 90 degree counterclockwise with a hexagonal wrench key to
- open valve.

 Close it after 5 seconds, and check for gas leakage.


 Using soapy water, check for gas leakage from indoor unit's flare and outdoor unit's flare and valve rods.

 Wipe off all the water after completing the check.

 (7) Disconnect charging hose from gas service valve's service port and fully open liquid and gas service valves. (Do not attempt to turn valve rod beyond its stop.)

 (8) Tighten service valve caps and service port cap to the specified torque shown in the table below.

Service valve size (mm)	Service valve cap tightening torque (N·m)	Service port cap tightening torque (N·m)	
ø6.35 (1/4")	20.20		
ø9.52 (3/8")	20-30	10-12	
ø12.7 (1/2")	25-35		



↑ CAUTION

To prevent vacuum pump oil from entering into the refrigerant system, use a counterflow prevention adapter.

5. Additional refrigerant charge

Additional refrigerant charge is required only when connecting pipe length exceeds 15 m.

 $\begin{array}{l} \textbf{5.1 Calculating additional refrigerant charge} \\ \textbf{Additional refrigerant charge can be calculated using the formula given below.} \\ \textbf{Additional refrigerant charge (g) = { Connecting pipe length (m) - Factory charged length 15 (m) } x 20 (g/m) \\ \textbf{Additional refrigerant charge (g) = { Connecting pipe length (m) - Factory charged length 15 (m) } x 20 (g/m) \\ \textbf{Additional refrigerant charge (g) = { Connecting pipe length (m) - Factory charged length 15 (m) } x 20 (g/m) \\ \textbf{Additional refrigerant charge (g) = { Connecting pipe length (m) - Factory charged length 15 (m) } x 20 (g/m) \\ \textbf{Additional refrigerant charge (g) = { Connecting pipe length (m) - Factory charged length 15 (m) } x 20 (g/m) \\ \textbf{Additional refrigerant charge (g) = { Connecting pipe length (m) - Factory charged length 15 (m) } x 20 (g/m) \\ \textbf{Additional refrigerant charge (g) = { Connecting pipe length (m) - Factory charged length 15 (m) } x 20 (g/m) \\ \textbf{Additional refrigerant charge (g) = { Connecting pipe length (m) - Factory charged length 15 (m) } x 20 (g/m) \\ \textbf{Additional refrigerant charge (g) = { Connecting pipe length (m) - Factory charged length 15 (m) } x 20 (g/m) \\ \textbf{Additional refrigerant charge (g) = { Connecting pipe length (m) - Factory charged length 15 (m) } x 20 (g/m) \\ \textbf{Additional refrigerant charge (g) = { Connecting pipe length (m) - Factory charged length (m) - Factory charged length (m) } x 20 (g/m) \\ \textbf{Additional refrigerant charge (g) = { Connecting pipe length (m) - Factory charged length (m) - Factory charged length (m) } x 20 (g/m) \\ \textbf{Additional refrigerant charge (g) = { Connecting pipe length (g) - Factory charged length (g) - Factory charged length (g) } x 20 (g/m) \\ \textbf{Additional refrigerant charge (g) = { Connecting pipe length (g) - Factory charged length (g) } x 20 (g/m) \\ \textbf{Additional refrigerant charge (g) = { Connecting pipe length (g) - Factory charged length (g) } x 20 (g/m) \\ \textbf{Additional refrigerant charged (g) } x 20 (g/m) \\ \textbf{Additional refrigerant charged (g) } x 20 (g/m) \\ \textbf{Additional refr$

NOTE

- If additional refrigerant charge calculation result is negative, there is no need to remove the refrigerant.
 If refrigerant recharge is required for the unit with connecting pipe length 15m or shorter, charge the
- factory charged amount as shown in the table below.

	Model SRC20/25	Model SRC35	Model SRC50
The factory refrigerant charge amount(kg)	0.62	0.78	1.05
The maximum refrigerant charge amount(kg)	0.72	0.88	1.25

5.2 Charging refrigerant

- 5.2 Charging refrigerant (1) Charge the R32 refrigerant in liquid phase from service port with both liquid and gas service valves shut. Since R32 refrigerant must be charged in the liquid phase, make sure that refrigerant is discharged from the cylinder in the liquid phase all the time.
 (2) When it is difficult to charge a required refrigerant amount, fully open both liquid and gas service valves and charge refrigerant, while running the unit in the cooling mode. When refrigerant is charged with the unit being run, complete the charge operation within 30 minutes.
 (3) Write the additional refrigerant charge calculated from the connecting pipe length on the label attached on the service over
- tached on the service cover.

△ CAUTION

Running the unit with an insufficient quantity of refrigerant for a long time can cause unit malfunction.

Do not charge more than the maximum refrigerant amount. It can cause unit malfunction.

NOTE

- Consult with our distributor in the area, if you need to recover refrigerant and charge it again.

- (2) Clean the existing pipe system according to the procedure given below.

 (a) Carry out forced cooling operation of existing unit for 30 minutes.

 For 'Forced cooling operation' refer to the indoor unit installation manual.

 (b) Stop the indoor fan and carry out forced cooling operation for 3 minutes (Liquid return).

 (c) Close the liquid service valve of the outdoor unit and carry out pump down operation (Refer to 6. PUMP DOWN).

 (d) Blow with pitrogen gas. If discolored refrigeration oil or any foreign matter is discharged by the
- (d) Blow with nitrogen gas. If discolored refrigeration oil or any foreign matter is discharged by the
- blow, wash the pipe system or install a new pipe system.

 (3) Remove the flare nuts from the existing pipe system. Go back to 4.CONNECTING PIPING WORK and proceed to step 2.2 Cutting connecting pipe.

⚠ CAUTION


- Do not use the old flare nuts (of existing unit). Make sure that the flare nuts supplied with the (new) outdoor unit are used.
 If the flared / compression connection to the indoor unit is located inside the house / room then this pipework can't be reused.
- If the existing piping is specified as liquid pipe ø9.52 or gas pipe ø12.7, refer to the following. (SRC50
- only) <Table of pipe size restrictions

Additional cha	rge volume per meter of pipe	0.054kg/m	
Discoules	Liquid pipe	ø9.52	
Pipe size Gas pipe		ø12.7	
Maximum one-way pipe length		10	
Length covered without additional charge		5	

Additional charge amount (kg) = {Main pipe length (m) - Length covered without additional charge shown in the table (m)} X Additional charge amount per meter of pipe shown in the table (kg/m)

6. PUMP DOWN

- (1) Connect charge hose of gauge manifold to service port of outdoor unit.
 (2) Close the liquid service valve with hexagonal wrench key.
 (3) Fully open the gas service valve with hexagonal wrench key.
 (4) Carry out forced cooling operation (For forced cooling operation procedure, refer to indoor unit installation
- (5) When the low pressure gauge becomes 0.01MPa, close the gas service valve and stop forced cooling



7. ELECTRICAL WIRING WORK

⚠ WARNING

- Make sure that all the electrical work is carried out in accordance with the national or regional electrical
- Make sure true and the electrical marks of constructions and construction of constructions. Make sure that the earth leakage breaker and circuit breaker of appropriate capacities are installed (Refer to the table given below).

 Do not turn on the power until the electrical work is completed.

 Do not use a condensive capacitor for power factor improvement under any circumstances. (It does not improve power factor. Moreover, it can cause an abnormal overheat accident).

Breaker specifications

Model	Phase	Earth leakage breaker	Circuit breaker	
SRC20/25/35	Cinala abasa	Leakage current: 30mA,	Over current: 16A	
SRC50	Single phase	0.1sec or less	Over current: 20A	

Main fuse specification

Model	Specification	Parts No.	Code on LABEL, WIRING
SRC20/25/35	250V 15A	SSA564A136	F7
SRC50	250V 20A	SSA564A136A	F4

1.Preparing cable


(1) Selecting cable

- Select the power source cable and connecting cable in accordance with the specifications mentioned below
- (a) Power source cable 3 cores* 2.5mm² or more, conformed with 60245 IEC57
- 3 cores* 2.5mm* or more, conformed with 60245 IEC57
 When selecting the power source cable length, make sure that voltage drop is less than 2%.
 If the wire length gets longer, increase the wire diameter.
 (b) Connecting cable
 4 cores* 1.5mm*, conformed with 60245 IEC57
 * 1 Earth wire is included (Yellow/Green).
 Arrange each wire length as shown below.
 Make sure that each wire is stripped 10mm from the end.



(3) Attach round crimp-type terminal to each wire as shown in the belo

Select the size of round crimp-type terminal after considering the specifications of terminal block and wire diameter.



Power source cable and connecting cable must conform to the specifications mentioned in the manual. Using cables with wrong specifications may result in unit malfunction.

2.Connecting cable

- (1) Remove the service cover.(2) Connect the cables according to the instructions and figures given below.

 - Connect the cables according to the instructions and figures given below.

 (a) Connect the earth wire of power source cable.

 An earth wire must be connected before connecting the other wires of power source cable.

 Keep the earth wire longer than the remaining two wires of power source cable.


 (b) Connect the remaining two wires (N and L) of power source cable.


 (c) Connect the wires of connecting cable. Make sure that for each wire, outdoor and indoor side terminal numbers match.
- (3) Fasten the cables properly with cable clamps so that no external force may work on terminal connect

tions.

Moreover, make sure that cables do not touch the piping, etc. When cables are connected, make sure that all electrical components within the electrical component box are free of loose connector coupling or terminal connection.

<Circuit diagram>





Thissning work
 Make sure that the exterior portion of connecting pipes, connecting cable and drain hose is wrapped properly with tape. Shape the connecting pipes to match with the contours of the pipe assembly route.
 Fix the pipe assembly with the wall using clamps and screws. Pipe assembly should be anchored every 1.5m or less to isolate the vibration.
 Install the service cover securely. Water may enter the unit if service cover is not installed properly, resulting in unit malfunction and failure.

8. FINISHING WORK


1. Heating and condensation prevention

- (1) Dress the connecting pipes (both liquid and gas pipes) with insulation to prevent it from heating and dew condensation.

 Use the heat insulating material which can withstand 120°C or higher temperature. Make sure that
- insulation is wrapped tightly around the pipes and no gap is left between them.
- (2) Wrap the refrigerant pipings of indoor unit with indoor unit heat insulation using tape.

 (3) Cover the flare-connected joints (indoor side) with the indoor unit heat insulation and wrap it with an insulation pad (standard accessory provided with indoor unit).

 (4) Wrap the connecting pipes, connecting cable and drain hose with the tape.



NOTE

Locations where relative humidity exceeds 70%, both liquid and gas pipes need to be dressed with 20mm or thicker heat insulation materials.

A CAUTION

- Improper insulation can cause condensate(water) formation during cooling operation.
- Condensate can leak or drip causing damage to household property
- Poor heat insulating capacity can cause pipe outer surface to reach high temperature during heating operation. It can cause cable deterioration and personal injury.

2.Finishing work

△ CAUTION Make sure that the connecting pipes do not touch the components within the unit. If pipes touch the internal components, it may generate abnormal sounds and/or vibrations

9. INSTALLATION TEST CHECK POINTS

After finishing the installation work, check the following points again before turning on the power Conduct test run (Refer to indoor unit installation manual) and ensure that the unit operates properly

Power source voltage complies with the rated voltage of air-conditioner. Earth leakage breaker and circuit breaker are installed. Power cable and connecting cable are securely fixed to the terminal block Both liquid and gas service valves are fully open

No gas leaks from the joints of the service valves.	
Indoor and outdoor side pipe joints have been insulated.	
Drain hose (if installed) is fixed properly.	
Screw of the service cover is tightened properly.	

(3) Safety precautions in handling air-conditioners with flammable refrigerants

WALL TYPE AIR-CONDITIONER R32 REFRIGERANT USED

RSA012A061A



This equipment uses flammable refrigerants. If the refrigerant is leaked, together with an external ignition source, there is a possibility of ignition.



There is information included in the user's manual and/or installation manual.



The user's manual should be read carefully.

A service personnel should be handing this equipment with reference to the installation manual.

The precautionary items mentioned below are distinguished into two levels, <u>MWARNING</u> and <u>MCAUTION</u>.

MARNING: Wrong installation would cause serious consequences such as injuries or death.

⚠ CAUTION: Wrong installation might cause serious consequences depending on circumstances.

⚠ WARNING

- Strict compliance of the domestic laws must be observed when disposing the appliance.
- observed when disposing the appliance.
 Do not use means to accelerate the defrost operation process or to clean, other than those recommended by the manufacturer.
- The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater.
- · Do not pierce or burn.
- Be aware that refrigerants may not contain an odour.
- The indoor unit shall be stored in a room that has a minimum area of 4.0 m².

⚠ CAUTION

1. General

- That the installation of pipe-work shall be kept to a minimum
- That pipe-work shall be protected from physical damage.
- That compliance with national gas regulations shall be observed.
 That mechanical connections shall be accessible
- That mechanical connections shall be accessible for maintenance purposes.
- Keep any required ventilation openings clear of obstruction.
- Servicing shall be performed only as recommended by the manufacturer.

2. Unventilated areas

 The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.

3. Qualification of workers

 The staff in servicing operations must hold the national qualification or other relevant qualifications.

4. Information on servicing

- 4.1 Checks to the area
- Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimised.
- For repair to the refrigerating system, 4.3 to 4.7 shall be completed prior to conducting work on the system.
- 4.2 Work procedure
- Work shall be undertaken under a controlled procedure so as to minimise the risk of a flammable gas or vapour being present while the work is being performed.
- 4.3 General work area
- All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out.
- Work in confined spaces shall be avoided.
- The area around the workspace shall be sectioned off.
- Ensure that the conditions within the area have been made safe by control of flammable material.
- 4.4 Checking for presence of refrigerant
- The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres.
- Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e.
- non-sparking, adequately sealed or intrinsically safe.

- 4.5 Presence of fire extinguisher
- If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO₂ fire extinguisher adjacent to the charging area.
- 4.6 No ignition sources
- No person carrying out work in relation to a refrigeration system which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion.
- All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space.
- Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks.
- "No Smoking" signs shall be displayed.
- 4.7 Ventilated area
- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work.
- A degree of ventilation shall continue during the period that the work is carried out.
- The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.
- 4.8 Checks to the refrigeration equipment
- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification
- At all times the manufacturer's maintenance and service guidelines shall be followed.
- If in doubt consult the manufacturer's technical department for assistance.
- The following checks shall be applied to installations using flammable refrigerants:
 - the charge size is in accordance with the room size within which the refrigerant containing parts are installed:
- the ventilation machinery and outlets are operating adequately and are not obstructed;
- if an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant;
- marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
- refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

- 4.9 Checks to electrical devices
- Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures.
- If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with.
- If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used.
- This shall be reported to the owner of the equipment so all parties are advised.
- Initial safety checks shall include:
- that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- that no live electrical components and wiring are exposed while charging, recovering or purging the system:
- that there is continuity of earth bonding.

5. Repairs to sealed components

- During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc.
- If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.
- Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected.
- This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.
- Ensure that the apparatus is mounted securely.
- Ensure that seals or sealing materials have not degraded to the point that they no longer serve the purpose of preventing the ingress of flammable atmospheres.
- Replacement parts shall be in accordance with the manufacturer's specifications.

NOTE

The use of silicon sealant can inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.

⚠ CAUTION

6. Repair to intrinsically safe components

- Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.
- Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere.
- The test apparatus shall be at the correct rating
- Replace components only with parts specified by the manufacturer.
- Other parts may result in the ignition of refrigerant in the atmosphere from a leak

7. Cabling

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

8. Detection of flammable refrigerants

- Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks.
- A halide torch (or any other detector using a naked flame) shall not be used.

9. Leak detection methods

- Electronic leak detectors may be used to detect refrigerant leaks but, in the case of flammable refrigerants, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.)
- Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used
- Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed.
- Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.
- If a leak is suspected, all naked flames shall be removed/extinguished.
- If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak
- For appliances containing flammable refrigerants, oxygen free nitrogen (OFN) shall then be purged through the system both before and during the brazing process.

10. Removal and evacuation

- · When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants it is important that best practice is
- followed since flammability is a consideration. The following procedure shall be adhered to: remove refrigerant;

 - purge the circuit with inert gas;
- evacuate:
- purge again with inert gas;
- open the circuit by cutting or brazing.
- The refrigerant charge shall be recovered into the correct recovery cylinders. For appliances containing flammable refrigerants,
- the system shall be "flushed" with OFN to render the unit safe. This process may need to be repeated several
- times.
- Compressed air or oxygen shall not be used for purging refrigerant systems.

For appliances containing flammable refrigerants, flushing shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be repeated until no refrigerant is within the system.

- When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.
- This operation is absolutely vital if brazing operations on the pipe-work are to take place.
- Ensure that the outlet for the vacuum pump is not close to any ignition sources and that ventilation is available

(11. Charging procedures

- In addition to conventional charging procedures, the following requirements shall be followed
- Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimise the amount of refrigerant contained in
- Cylinders shall be kept upright.
- Ensure that the refrigeration system is earthed prior to charging the system with refrigerant
- Label the system when charging is complete (if not already).
- Extreme care shall be taken not to overfill the refrigeration system.
- Prior to recharging the system, it shall be pressure-tested with the appropriate purging gas.
- The system shall be leak-tested on completion of charging but prior to commissioning.

 A follow up leak test shall be carried out prior to
- leaving the site.

12. Decommissioning

- Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail.
- It is recommended good practice that all refrigerants are recovered safely.
- Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of reclaimed refrigerant.
- It is essential that electrical power is available before the task is commenced.
- a) Become familiar with the equipment and its operation.
- b) Isolate system electrically.
- c) Before attempting the procedure ensure that: - mechanical handling equipment is available, if required, for handling refrigerant cylinders;
- all personal protective equipment is available and being used correctly;
- the recovery process is supervised at all times by a competent person;
- recovery equipment and cylinders conform to the appropriate standards.
- d) Pump down refrigerant system, if possible.
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f) Make sure that cylinder is situated on the scales before recovery takes place.
- g) Start the recovery machine and operate in accordance with manufacturer's instructions.
- h) Do not overfill cylinders. (No more than 80 %
- volume liquid charge).

 Do not exceed the maximum working pressure of the cylinder, even temporarily.
- When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

13. Labelling

- Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed.
- For appliances containing flammable refrigerants, ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.


14. Recovery

- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed
- When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed.
- Ensure that the correct number of cylinders for holding the total system charge are available.
- All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant).
- Cylinders shall be complete with pressure relief valve and associated shut-off valves in good
- Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants
- including, when applicable, flammable refrigerants. In addition, a set of calibrated weighing scales shall be available and in good working order.
- Hoses shall be complete with leak-free disconnect
- couplings and in good condition. Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt.
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste Transfer Note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant.
- The evacuation process shall be carried out prior to returning the compressor to the suppliers.
- Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be
- carried out safely.

(15. Other safety precautions

- · A brazed, welded, or mechanical connection shall be made before opening the valves to permit refrigerant to flow between the refrigerating system parts.
- Flammable refrigerant used, refrigerant tubing protected or enclosed to avoid mechanical damage (IEC/EN 60335-2-40/A1).
- Tubing protected to extent that it will not be handled or used for carrying during moving of product (IEC/EN 60335-2-40/A1).
- Flammable refrigerant used, low temperature solder alloys, such as lead/tin alloys, not acceptable for pipe connections (IEC/EN 60335-2-40/A1).
- When there is flare connection, it must be installed outdoor

9. OUTLINE OF OPERATION CONTROL BY MICROCOMPUTER



• RUN and TIMER lights blink quickly during invalid operation mode.

(2) Unit ON/OFF button

When the wireless remote control batteries become weak, or if the wireless remote control is lost or malfunctioning, this button may be used to turn the unit on and off.


(a) Operation

Push the button once to place the unit in the automatic mode. Push it once more to turn the unit off.

(b) Details of operation

The unit will go into the automatic mode in which it automatically determines, from room temperature (as detected by sensor), whether to go into the COOL or HEAT modes.

Function Operation mode	Room temperature setting	Fan speed	Flap/Louver	Timer switch
COOL	About 24°C	Auto	Auto	Continuous
HEAT	About 26°C	Auto	Auto	Continuous




(3) Auto restart function

- (a) Auto restart function records the operational status of the air-conditioner immediately prior to be switched off by a power cut, and then automatically resumes operations after the power has been restored.
- (b) The following settings will be cancelled:
 - (i) Timer settings
 - (ii) HIGH POWER operation

Notes (1) Auto restart function is set at on when the air-conditioner is shipped from the factory. Consult with your dealer if this function needs to be switched off.

- (2) When power failure ocurrs, the timer setting is cancelled. Once power is resumed, reset the timer.
- (3) If the jumper wire (J1) "AUTO RESTART" is cut, auto restart is disabled. (See the diagram at right.)



(4) Installing two air-conditioners in the same room


In case two air-conditioners are installed in the same room, apply this setting so that one unit can be operated with only one remote control.


(a) Setting the wireless remote control

- (i) Slide the cover and take out the batteries.
- (ii) Disconnect the switching line next to the battery with wire cutters.
- (iii) Set the batteries and cover again.

(b) Setting an indoor unit

- (i) Turn off the power source, and turn it on after 1 minute.
- (ii) Point the wireless remote control (that was set according to the procedure described on the left side) at the indoor unit and send a signal by pressing the ACL switch on the wireless remote control.
 - Since the signal is sent in about 6 seconds after the ACL switch is pressed, point the wireless remote control at the indoor unit for some time.
- (iii) Check that the reception buzzer sound "Peep" is emitted from the indoor unit.At completion of the setting, the indoor unit emits a buzzer sound "Peep".(If no reception sound is emitted, start the setting from the beginning again.)





Jumper wire (J3)

(5) Selection of the annual cooling function

(a) The annual cooling control is valid from factory default setting. It is possible to disable by cutting jumper wire (J3), or changing the setting of dip switch (SW2-4) on the interface kit (option) PCB if it is connected.


Jumper wire (J3)	Interface kit (SC-BIKN2-E) SW2-4	Function
Shorted	ON	Enabled
Shorted	OFF	Disabled
Open	ON	Disabled
Open	OFF	Disabled

Note: (1) Default states of the jumper wire (J3) and the interface kit at the shipping from factory –On the PCB, the dip switch (SW2-4) is set to enable the annual cooling function.

(2) To cancel the annual cooling setting, consult your dealer.

(b) Content of control


- (i) If the outdoor air temperature sensor (TH2) detects below 5°C, the indoor unit speed is switched to 7th step.
- (ii) If the outdoor air temperature sensor (TH2) detects higher than 10°C, the indoor unit speed is changed to the normal control speed.



(a) Heating only function is enabled by disconnecting the jumper wire (J4).

(b) Content of control

Operation mode setting	Operation mode
COOL/DRY/FAN	FAN
AUTO/HEAT	HEAT



ON

5

10

Outdoor air temperature (°C)

(7) High power operation

Pressing the HI POWER/ECONOMY button intensifies the operating power and initiates powerful cooling and heating operation for 15 minutes continuously. The wireless remote control displays HIGH POWER mark and the FAN SPEED display disappears.

- (a) During the HIGH POWER operation, the room temperature is not controlled. When it causes an excessive cooling and heating, press the HI POWER/ECONOMY button again to cancel the HIGH POWER operation.
- (b) HIGH POWER operation is not available during the DRY and the ON timer to OFF timer operations.
- (c) When HIGH POWER operation is set after ON timer operation, HIGH POWER operation will start from the set time.
- (d) When the following operation are set, HIGH POWER operation will be cancelled.
 - ① When the HI POWER/ECONOMY button is pressed again.
 - ② When the operation mode is changed.
 - ③ When it has been 15 minutes since HIGH POWER operation has started.
 - 4 When the 3D AUTO botton is pressed.
 - ⑤ When the SILENT botton is pressed.
 - **(6)** When the NIGHT SETBACK botton is pressed.
- (e) Not operable while the air-conditioner is OFF.
- (f) After HIGH POWER operation, the sound of refrigerant flowing may be heard.

(8) Economy operation

Pressing the HI POWER/ECONOMY button initiates a soft operation with the power suppressed in order to avoid an excessive cooling or heating. The unit operate 1.5°C higher than the setting temperature during cooling or 2.5°C lower than that during heating. The wireless remote control displays ECONOMY mark and the FAN SPEED display disappears.

- (a) It will go into ECONOMY operation at the next time the air-conditioner runs in the following cases.
 - ① When the air-conditioner is stopped by ON/OFF button during ECONOMY operation.
 - ② When the air-conditioner is stopped in SLEEP or OFF TIMER operation during ECONOMY operation.
 - ③ When the operation is retrieved from CLEAN or ALLERGEN CLEAR operation.
- (b) When the following operation are set, ECONOMY operation will be cancelled.
 - ① When the HI POWER/ECONOMY button is pressed again.
 - ② When the operation mode is changed from DRY to FAN.
 - ③ When the NIGHT SETBACK botton is pressed.
- (c) Not operable while the air-conditioner is OFF.
- (d) The setting temperature is adjusted according to the following table.

Item Mode	Cooling	Heating
Т	(1)+0.5	①-1.0
Temperature adjustment	②+1.0	②-2.0
3	③+1.5	3-2.5


- ① at the start of operation.
- ② one hour after the start of operation.
- 3 two hours after the start of operation.

(9) Air flow direction adjustment

Air flow direction can be adjusted with by AIR FLOW ♦ (UP/DOWN) and ♠ (LEFT/RIGHT) button on the wireless remote control.

(a) Flap

Every time when you press the AIR FLOW \(\Display(UP/DOWN) \) button the mode changes as follows.




Angle of flap from horizontal

Wireless remote control display	-7	, J	Ţ	7	Ş
COOL, DRY, FAN	Approx. 25°	Approx. 30°	Approx. 40°	Approx. 50°	Approx. 60°
HEAT	Approx. 25°	Approx. 35°	Approx. 50°	Approx. 60°	Approx. 70°

(b) Louver

Every time when you press the AIR FLOW (LEFT/RIGHT) button the mode changes as follows.




· Angle of louver

Wireless remote control display					
Center installation	Left approx. 50°	Left approx. 20°	Center	Right approx. 20°	Right approx. 50°
Right end installation	Left approx. 50°	Left approx. 45°	Left approx. 30°	Center	Right approx. 20°
Left end installation	Left approx. 20°	Center	Right approx. 30°	Right approx. 45°	Right approx. 50°

(c) Swing

- (i) Swing flap
 Flap moves in upward and downward directions continuously.
- (ii) Swing louver

 Louver moves in left and right directions continuously.



(d) Memory flap (Flap or louver stopped)

When you press the AIR FLOW (UP/DOWN or LEFT/RIGHT) button once while the flap or louver is operating, it stops swinging at the position. Since this angle is memorized in the microcomputer, the flap or louver will automatically be set at this angle when the next operation is started.

(10) 3D auto operation

Control the flap and louver by 3D AUTO button on the wireless remote control.

Fan speed and air flow direction are automatically controlled, allowing the entire indoor to efficiently conditioned.

- (a) During cooling and heating (Including auto cooling and heating)
 - (i) Air flow selection is determined according to indoor temperature and setting temperature.

Operation mode	Air flow selection						
Operation mode	AL	AUTO			LO		
Cooling	Room temp. – Setting temp. >5°C	Room temp. – Setting temp. $\leq 5^{\circ}$ C					
Cooling	HIGH POWER	AUTO	НІ	MED	LO		
Heating	Setting temp. – Room temp. >5°C	Setting temp. – Room temp. ≤ 5°C			LO		
пеанну	HIGH POWER	AUTO			<u> </u>		

- (ii) Air flow direction is controlled according to the room temperature and setting temperature.
 - 1) When 3D auto operation starts

	Cooling	Heating			
Flap	Up/down swing				
Louver	Wide (Fixed)	Center (Fixed)			

When Room temp. – Setting temp. is $\leq 5^{\circ}$ C during cooling and when setting temp. – Room temp. is $\leq 5^{\circ}$ C during heating, the system switches to the following air flow direction control. After the louver swings left and right symmetrically for 3 cycles, control is switched to the control in 3).

	Cooling	Heating		
Flap	Horizontal blowing (Fixed)	Slant forwardl blowing (Fixed)		
Louver	Left/right swing			

3) After the flap swings for 5 cycles, control is switched to the control in 4).

	Cooling Heating			
Flap	Up/down swing			
Louver	Center (Fixed)			

4) For 5 minutes, the following air flow direction control is carried out.

	Cooling Heating			
Flap	Horizontal blowing (Fixed)	Slant forwardl blowing (Fixed)		
Louver	Wide (Fixed)			

5) After 5 minutes have passed, the air flow direction is determined according to the room temperature and setting temperature.

Operation mode	Air flow direction contorol					
Cooling	Room temp. – Setting temp. ≦2°C	$2^{\circ}\text{C} < \text{Room temp.} - \text{Setting temp.} \leq 5^{\circ}\text{C}$	Room temp. – Setting temp. > 5 °C			
Cooling	The control in 4) continues.	Control returns to the control in 2).	Control returns to the control in 1).			
Heating	Setting temp. – Room temp. $\leq 2^{\circ}$ C 2° C < Setting temp. – Room temp. $\leq 5^{\circ}$ C		Setting temp. − Room temp. > 5°C			
Heating	The control in 4) continues.	Control returns to the control in 2).	Control returns to the control in 1).			

(b) During DRY operation

Flap	Horizontal blowing (Fixed)		
Louver	Wide (Fixed)		

(11) Timer operation

(a) Comfort start-up (ON timer operation)

The unit starts the operation 5 to 60 minutes earlier so that the room can approach optimum temperature at ON timer.

(b) Sleep timer operation

Pressing the SLEEP button causes the temperature to be controlled with respect to the set temperature.

(c) OFF timer operation

The OFF timer can be set at a specific time (in 10-minute units) within a 24-hour period.

(d) Weekly timer operation

Up to 4 programs with timer operation (ON timer / OFF timer) are available for each day of the week.

(12) Silent operation

When the silent operation is set, the unit operates by dropping the outdoor fan speed and the compressor speed.

	SRK20		SRK25		SRK35		SRK50	
	Cooling	Heating	Cooling	Heating	Cooling	Heating	Cooling	Heating
Outdoor fan speed (Upper limit)	4th speed	4th speed	4th speed	4th speed	5th speed	4th speed	4th speed	4th speed
Compressor speed (Upper limit)	30 rps	46 rps	37 rps	49 rps	46 rps	56 rps	46 rps	70rps

(13) Night setback operation

When the night setback operation is set, the heating operation starts with the setting temperature at 10°C.

(14) Air flow range setting

Take the air-conditioner location into account and adjust the left/right air flow range to maximize air-conditioning.

(a) Setting

(i) If the air-conditioning unit is running, press the ON/OFF button to stop.The installation location setting cannot be made while the unit is running.

(ii) Press the AIR FLOW U/D (UP/DOWN) button and the AIR FLOW L/R (LEFT/RIGHT) button together for 5 seconds or more.


The installation location display illuminates.


(iii) Setting the air-conditioning installation location.

Press the AIR FLOW L/R (LEFT/RIGHT) button and adjust to the desired location.

Each time the AIR FLOW L/R (LEFT/RIGHT) button is pressed, the indicator is switched in the order of:
















(Right end installation)

(iv) Press the ON/OFF button.

The air-conditioner's installation location is set.

Press within 60 seconds of setting the installation location (while the installation location setting display illuminates).

(15) Display brightness adjustment

This function can be used when it is necessary to adjust the brightness of unit display.

Brightness level	Run light	Timer light
LV2	100%	100%
LV1	50%	50%
LV0	0%	0%

Note(1) When the unit displays self diagnosis or service mode, brightness level is always LV2.

(16) Outline of heating operation

(a) Operation of major functional components in heating mode

		Heating	
	Thermostat ON	Thermostat OFF	Failure
Compressor	ON	OFF	OFF
Indoor fan motor	ON	ON(HOT KEEP)*	OFF
Outdoor fan motor	ON	OFF (few minutes ON)	OFF
4-way valve	ON	ON	OFF (3 minutes ON)

^{*}It can be set the indoor fan motor off or the heating thermostat OFF with connecting a wired remote control. In the case, indoor air temperature is detected by sensor on the wired remote control.

(b) Details of control at each operation mode (pattern)

(i) Fuzzy operation

Deviation between the indoor temperature setting correction temperature and the return air temperature is calculated in accordance with the fuzzy rule, and used for control of the air capacity and the compressor speed.

Model Fan speed	SRK20	SRK25	SRK35	SRK50
Auto	20-115rps	20-115rps	20-115rps	20-110rps
HI	20-115rps	20-115rps	20-115rps	20-110rps
MED	20-86rps	20-104rps	20-108rps	20-106rps
LO	20-70rps	20-84rps	20-96rps	20-94rps
ULO	20-44rps	20-54rps	20-60rps	20-63rps

When the defrost operation, protection device, etc. is actuated, operation is performed in the corresponding mode.


(ii) Hot keep operation

During the heating operation, the indoor fan speed can be controlled based on the temperature of the indoor heat exchanger (Th2) to prevent blowing out of cold air.


(c) Defrost operation

- (i) Starting conditions (Defrost operation can be started only when all of the following conditions are satisfied.)
 - 1) After start heating operation
 - When it elapsed 35 minutes. (Total compressor operation time)
 - 2) After finish of defrost operation
 - When it elapsed 35 minutes. (Total compressor operation time)
 - 3) Outdoor heat exchanger sensor (TH1) temperature
 - When the temperature has been -5°C or less for 3 minutes continuously.
 - The difference between the outdoor air sensor temperature and the outdoor heat exchanger sensor temperature is as following.

Models SRK20, 25



Models SRK35, 50



- 5) During continuous compressor operation
 - In case satisfied all of following conditions.
 - Connect compressor speed 0 rps 10 times or more.
 - Satisfy 1), 2) and 3) conditions above.
 - Outdoor air temperature is 3°C or less.
- (ii) Ending conditions (Operation returns to the heating cycle when either one of the following is satisfied.)
 - 1) Outdoor heat exchanger sensor (TH1) temperature: 13°C (model SRK50 : 10°C) or higher
 - Continued operation time of defrost operation → For more than 17 minutes (models SRK35, 50: 17 minutes and 30 seconds).
 - Defrost operation



*Depends on an operation condition, the time can be longer than 7 minutes

(d) Countermeasure for excessive temperature rise

If it feels excessive temperature rise in heating operation, setting temperature can be lower.

(i) Setting

Push ON/OFF button 30 seconds or more after turn on the power source and operate the air-conditioner at least once time, At completion of the setting, the indoor unit emits a buzzer sound "Pip".

(ii) Contents of control

Unit: °C

		Signal of wireless remote control (Display)											
	18	19	20	21	22	23	24	25	26	27	28	29	30
Before setting	20	21	22	23	24	25	26	27	28	29	30	31	32
After setting	18	19	20	21	22	23	24	25	26	27	28	29	30

(iii) Reset condition

Push ON/OFF button 30 seconds or more during setting this mode. At completion of the reset, the indoor unit emits a buzzer sound "PiPiPi".

(17) Outline of cooling operation

(a) Operation of major functional components in cooling mode

		Cooling	
	Thermostat ON	Thermostat OFF	Failure
Compressor	ON	OFF	OFF
Indoor fan motor	ON	ON	OFF
Outdoor fan motor	ON	OFF (few minutes ON)	OFF (few minutes ON)
4-way valve	OFF	OFF	OFF

(b) Detail of control in each mode (Pattern)

(i) Fuzzy operation

During the fuzzy operation, the air flow and the compressor speed are controlled by calculating the difference between the indoor temperature setting correction temperature and the return air temperature.

Model Fan speed	SRK20	SRK25	SRK35	SRK50
Auto	15-66rps	15-74rps	15-98rps	20-100rps
HI	15-66rps	15-74rps	15-98rps	20-100rps
MED	15-52rps	15-60rps	15-80rps	20-82rps
LO	15-42rps	15-48rps	15-70rps	20-66rps
ULO	15-34rps	15-38rps	15-46rps	20-40rps


(18) Outline of dehumidifying (DRY) operation

(a) Purpose of DRY mode

The purpose is "Dehumidification", and not to control the humidity to the target condition. Indoor/outdoor unit control the operation condition to reduce the humidity, and also prevent over cooling.

(b) Outline of control

(i) Indoor unit fan speed and compressor are controlled by the area which is selected by the temperature difference.



Difference between set temperature and indoor air temperature

(ii) The indoor unit checks the current area by every 5 minutes, and operates by the next checking.


(c) Other

When the outdoor air temperature and room temperature are low in cooling operation, indoor unit can not operate cooling mode, and DRY mode. In this case, the unit operates in heating mode to rise the indoor air temperature and after that start DRY mode.


(19) Outline of automatic operation

(a) Determination of operation mode

Operation mode is determined by indoor air temperature and outdoor air temperature as following.



(b) Operation mode is changes when keep cooling and heating thermostat off 20 minutes and be satisfied with following conditions. If the setting temperature is changed with the remote control, the operation mode is judged immediately.



Indoor air temperature – Setting temperature (°C)

XIt can not be changed to heating mode if outdoor air temperature is 28°C or higher.

- (c) When the unit is started again within one hour after the stop of automatic operation or when the automatic operation is selected during heating, cooling or DRY mode, the unit is operated in the previous operation mode.
- (d) Setting temperature can be adjusted within the following range. There is the relationship as shown below between the signals of the wireless remote control and the setting temperature.

 Unit: $^{\circ}$ C

				Sig	nals of v	wireless	remote	control	(Display	r)				
		18	19	20	21	22	23	24	25	26	27	28	29	30
Setting	Cooling	18	19	20	21	22	23	24	25	26	27	28	29	30
temperature	Heating	20	21	22	23	24	25	26	27	28	29	30	31	32

(e) When the unit is operated automatically with the wired remote control, the cooling operation is controlled according to the display temperatures while the setting temperature is compensated by $+2^{\circ}$ C during heating.

(20) Protective control function

Dew prevention control (During cooling)

Prevents dewing on the indoor unit. (SRK35, 50 only)

Operating conditions

When the following conditions have been satisfied for more than 30 minutes after starting operation


- Compressor's speed is 32 (model SRK50:28) rps or higher.
- 2) Detected value of humidity is 68% or higher.

(ii) Contents of operation

Air capacity control 1)

Item	Model	SRK35	SRK50
LO	Upper limit of compressor's speed	RangeA: 60rps, RangeB: 60rps	RangeA: 62rps, RangeB: 50ps
LO	Indoor fan	5th speed	4th speed
	Upper limit of compressor's speed	RangeA: 60rps, RangeB: 60rps	RangeA: 62rps, RangeB: 50rps
AUTO,HI,MED	Indoor fan	Adaptable to co	ompressor speed
	Indoor ian	(Lower limit 5th speed)	(Lower limit 4th speed)

Note (1) Ranges A and B are as shown below.



- When this control has continued for more than 30 minutes continuously, the following wind direction control is performed.
 - a) When the vertical wind direction is set at other than the vertical swing, the flaps change to the horizontal position.
 - b) When the horizontal wind direction is set at other than the horizontal swing, the louver changes to the vertical position.

(iii) Reset condition

Humidity is less than 63%.


(b) Frost prevention control (During cooling or dehumidifying)

Operating conditions

- Indoor heat exchanger temperature (Th2) is lower than 5°C.
- 5 minutes after reaching the compressor speed except 0 rps.

(ii) Detail of anti-frost operation

Indoor heat exchanger temperature	5°C or lower	2.5°C or lower
Lower limit of compressor command speed	22 rps(model SRK50 : 23 rps)	0 rps
Indoor fan	Depends on operation mode	Keep the fan speed before frost prevention control
Outdoor fan	Depends on compressor speed	Depends on stop mode
4-way valve	OFF	Depends on stop mode



- Notes (1) When the indoor heat exchanger temperature is in the range of 2.5–5°C, the speed is reduced by 4 rps at each 20 seconds.
 (2) When the temperature is lower than 2.5°C, the compressor is stopped.
 (3) When the indoor heat exchanger temperature is in the range of 5–8°C, the compressor speed is been maintained.

(iii) Reset conditions

When either of the following condition is satisfied.


- 1) The indoor heat exchanger temperature (Th2) is 8°C or higher.
- The compressor speed is 0 rps.

(c) Cooling overload protective control

Operating conditions

When the outdoor air temperature (TH2) has become continuously for 30 seconds at 41°C or more, or 47°C or more with the compressor running, the lower limit speed of compressor is brought up.

Model	SRK	20-35	SRK50		
Outdoor air temperature	41°C or more	47°C or more	41°C or more	47°C or more	
Lower limit speed	30 rps	45 rps	27 rps	35 rps	



(ii) Detail of operation

- 1) The outdoor fan is stepped up by 3 speed step. [Upper limit 8 (model SRK50: 8) th speed.]
- 2) The lower limit of compressor speed is set to 30 or 45 (model SRK50: 27 or 35) rps. However, when the thermo OFF, the speed is reduced to 0 rps.

(iii) Reset conditions

When either of the following condition is satisfied.

- 1) The outdoor air temperature is lower than 40°C.
- 2) The compressor speed is 0 rps.

(d) Cooling high pressure control

(i) Purpose


Prevents anomalous high pressure operation during cooling.

Detector


Outdoor heat exchanger sensor (TH1).

(iii) Detail of operation

(Example) Compressor speed



		7	rH1(℃)
		P1	P2	Р3
SRK20, 25	Range A	47	50	53
SKK20, 20	Range B	53	58	63
CDIZOE EO	Range A	48	53	55
SRK35, 50	Range B	53	58	63



Notes (1) When the outdoor heat exchanger temperature is in the range of P2-P3°C, the speed is reduced by 6 rps at each 30 seconds.

(e) Cooling low outdoor air temperature protective control


Operating conditions

When the outdoor air temperature (TH2) is 22°C or lower continues for 20 seconds while the compressor speed is other than 0 rps.

(ii) Detail of operation


- It controls the upper and lower limit values for the compressor speed according to the following table. 1)
- It checks the outdoor temperature (TH2) once every hour to judge the operation range.

		Compressor speed: Upper/lower limit (rps)								
	Low Range B	er 1 Range A	Upper 1	Lower 2	Upper 2	Lower 3	Upper 3			
SRK20, 25, 35	30	Release	60	44	50	50	50			
SRK50	27	Release	60	44	50	_	_			



When the outdoor heat exchanger temperature is 13 °C or higher, the compressor is stopped.

When the outdoor heat exchanger temperature is in the range of P1-P2 °C, if the compressor speed is been maintained and the operation has continued for more than 30 seconds at the same speed, it returns to the normal cooling operation.



• Values of A, B, C, D, E, F (Models SRK20-35)

	Outdoor air temperature (°C)					
	E	F	Α	В	С	D
First time	-8	-5	0	3	22	25
After the second times	-2	1	5	8	25	28

• Values of A, B, C, D (Model SRK50)

	Outdoor air temperature (°C)			
	Α	В	С	D
First time	9	11	22	25
After the second times	16	19	25	28

(iii) **Reset conditions**

When either of the following condition is satisfied.

- The outdoor air temperature (TH2) is D°C or higher.
- The compressor speed is 0 rps.

(f) Heating high pressure control


Purpose

Prevents anomalous high pressure operation during heating.

Detector

Indoor heat exchanger sensor (Th2)

Detail of operation



Note (1) Value in () are for the model SRK50.

- Notes (1) When the indoor heat exchanger temperature is in the range of B-C °C, the speed is reduced by 4 rps at each 20 seconds.

 (2) When the indoor heat exchanger temperature is in the range of C-D °C, the speed is reduced by 8 rps at each 20 seconds. When the temperature is D °C or higher continues for 1 minute, the compressor is stopped.
 - (3) When the indoor heat exchanger temperature is in the range of A-B °C, if the compressor speed is been maintained and the operation has continued for more than 20 seconds at the same speed, it returns to the normal heating operation.
 - (4) Indoor fan retains the fan speed when it enters in the high pressure control. Outdoor fan is operated in accordance with the speed.

Temperature list

Models SRK20, 25, 35

Unit:					
	Α	В	С	D	
RPSmin < 50	47	52	54	58	
50 ≦ RPSmin < 92	47.5	55	57	61	
92 ≦ RPSmin ≦ 115	47.5 - 39	55 - 40	57 - 42	61	

Note (1) RPSmin: The lower one between the outdoor speed and the compressor speed

Model SRK50				Unit: °C
	Α	В	С	D
RPSmin < 35	49	54	55	55.5
35 ≦ RPSmin < 40	49 - 52	54 - 57	55 - 58	55.5 - 62
40 ≦ RPSmin < 80	52	57	58	62
80 ≦ RPSmin < 95	52 - 48.1	57 - 52.2	58 - 53.2	62 - 56
95 ≦ RPSmin < 115	48.1 - 43	52.2 - 46	53.2 - 47	56 - 50.5
115 ≦ RPSmin	43	46	47	50.5

Note (1) RPSmin: The lower one between the outdoor speed and the compressor speed

(g) Heating overload protective control

Outdoor unit side


• Models SRK20, 25, 35

1) Operating conditions


When the outdoor air temperature (TH2) is 22°C or higher continues for 30 seconds while the compressor speed other than 0 rps.

2) Detail of operation

- a) Taking the upper limit of compressor speed at 60 rps, if the output speed obtained with the fuzzy calculation exceeds the upper limit, the upper limit value is maintained.
- b) The lower limit of compressor speed is set to 40 rps and even if the calculated result becomes lower than that after fuzzy calculation, the speed is kept to 40 rps. However, when the thermostat OFF, the speed is reduced to 0 rps.
- c) Inching prevention control is activated and inching prevention control is carried out with the minimum speed set at 40 rps.
- d) The outdoor fan speed is set on 2nd speed.



Compressor speed:		
Lower limit	Upper limit	Outdoor fan speed
Range A Range B	Opper mint	1
40 Release	60	2nd



Indooor air temperature(°C)

3) Reset conditions

The outdoor air temperature (TH2) is lower than 21°C.


• Model SRK50

1) Operating conditions


When the outdoor air temperature (TH2) is 11°C or higher continues for 30 seconds while the compressor speed other than 0 rps.

2) Detail of operation

- a) Taking the upper limit of compressor speed range at 90 rps, if the output speed obtained with the fuzzy calculation exceeds the upper limit, the upper limit value is maintained.
- b) The lower limit of compressor speed is set to 27 rps and even if the calculated result becomes lower than that after fuzzy calculation, the speed is kept to 27 rps. However, when the thermostat OFF, the speed is reduced to 0 prs.
- Inching prevention control is activated and inching prevention control is carried out with the minimum speed set at 27 rps.
- d) Refer to the right table about the outdoor fan speed.



	Compressor	speed : Upper/			
	Lower limit		Upper limit	Outdoor fan speed	
	Range A	Range B	opper mint	_	
ON1	27	Release	90	It depends on compressor speed	
ON2	27	27	60	2nd	



3) Reset conditions

The outdoor air temperature (TH2) is lower than 10°C.

(h) Heating low outdoor temperature protective control


• Models SRK20, 25, 35

(i) Operating conditions

When the outdoor air temperature (TH2) is lower than -2°C or higher continues for 30 seconds while the compressor speed is other than 0 rps.

(ii) Detail of operation

The lower limit compressor speed is change as shown in the figure below.



(iii) Reset conditions

When either of the following condition is satisfied.

- 1) The outdoor air temperature (TH2) becomes 2°C.
- 2) The compressor speed is 0 rps.


Model SRK50

(i) Operating conditions

When the outdoor air temperature (TH2) is lower than 4°C or higher than 13°C continues for 30 seconds while the compressor speed is other than 0 rps.

(ii) Detail of operation

The lower limit compressor speed is change as shown in the figure below.



(iii) Reset conditions

When either of the following condition is satisfied.

- 1) The outdoor air temperature (TH2) becomes 6°C.
- The compressor speed is 0 rps.


(i) Compressor overheat protection

(i) Purpose

It is designed to prevent deterioration of oil, burnout of motor coil and other trouble resulting from the compressor overheat.

(ii) Detail of operation

1) Speeds are controlled with temperature detected by the sensor (TH3) mounted on the discharge pipe.



Notes (1) When the discharge pipe temperature is in the range of 100-110°C, the speed is reduced by 4 rps.

- (2) When the discharge pipe temperature is raised and continues operation for 20 seconds without changing, then the speed is reduced again by 4 rps.
- (3) If the discharge pipe temperature is in the range of 90-100°C even when the compressor speed is maintained for 60 seconds when the temperature is in the range of 90-100°C, the speed is raised by 1 rps and kept at that speed for 60 seconds. This process is repeated until the command speed is reached.

(4) Lower limit speed

Model	Item	Cooling	Heating
	SRK20 - 35	15 rps	20 rps
Lower limit speed	SRK50	20 rps	20 rps

2) If the temperature of 110°C is detected by the sensor on the discharge pipe, then the compressor will stop immediately. When the discharge pipe temperature drops and 3 minutes has elapsed, the unit starts again within 1 hour but there is no start at the third time.

(j) Current safe

(i) Purpose

Current is controlled not to exceed the upper limit of the setting operation current.

(ii) Detail of operation

Input current to the converter is monitored with the current sensor fixed on the printed circuit board of the outdoor unit and, if the operation current value reaches the limiting current value, the compressor speed is reduced.

If the mechanism is actuated when the compressor speed is less than 30 rps, the compressor is stopped immediately.

Operation starts again after 3 minutes.

(k) Current cut

(i) Purpose

Inverter is protected from overcurrent.

(ii) Detail of operation

Output current from the inverter is monitored with a shunt resistor and, if the current exceeds the setting value, the compressor is stopped immediately. Operation starts again after 3 minutes.

(I) Outdoor unit failure

This is a function for determining when there is trouble with the outdoor unit during air-conditioning.

The compressor is stopped if any one of the following in item (i), (ii) is satisfied. Once the unit is stopped by this function, it is not restarted.

- (i) When the input current is measured at 1 A or less for 3 continuous minutes or more.
- (ii) If the outdoor unit sends a 0 rps signal to the indoor unit 3 times or more within 20 minutes of the power being turned on.

(m) Indoor fan motor protection

When the air-conditioner is operating and the indoor fan motor is turned ON, if the indoor fan motor has operated at 300 min⁻¹ or under for more than 30 seconds, the unit enters first in the stop mode and then stops the entire system.

(n) Serial signal transmission error protection

(i) Purpose

Prevents malfunction resulting from error on the indoor ↔ outdoor signals.

(ii) Detail of operation

If the compressor is operating and a serial signal cannot be received from the indoor control with outdoor control having serial signals continues for 7 minutes and 35 seconds, the compressor is stopped.

After the compressor has been stopped, it will be restarted after the compressor start delay if a serial signal can be received again from the indoor control.

(o) Rotor lock

If the motor for the compressor does not turn after it has been started, it is determined that a compressor lock has occurred and the compressor is stopped.

(p) Outdoor fan motor protection

If the outdoor fan motor has operated at 75 min⁻¹ or under for more than 30 seconds, the compressor and fan motor are stopped.

(q) Outdoor fan control at low outdoor temperature

(i) Cooling

1) Operating conditions

When the outdoor air temperature (TH2) is 22°C or lower continues for 30 seconds while the compressor speed is other than 0 rps.

2) Detail of operation

After the outdoor fan operates at A speed for 60 seconds; the corresponding outdoor heat exchanger temperature shall implement the following controls.

• Value of A

	Outdoor fan
Outdoor temperature > 10°C	2nd speed
Outdoor temperature ≦ 10°C	1st speed

a) Outdoor heat exchanger temperature (TH1) ≤ 21°C

After the outdoor fan speed drops (down) to 1 speed for 60 seconds; if the outdoor heat exchanger temperature is lower than 21°C, gradually reduce the outdoor fan speed by 1 speed. (Lower limit 1st speed)

b) 21°C < Outdoor heat exchanger temperature (TH1) ≤ 38°C

After the outdoor fan speed maintains at A speed for 20 seconds; if the outdoor heat exchanger temperature is 21°C-38°C, maintain outdoor fan speed.

c) Outdoor heat exchanger tempeature (TH1) > 38°C

After the outdoor fan speed rises (up) to 1 speed for 60 seconds; if the outdoor heat exchanger temperature is higher than 38°C, gradually increase outdoor fan speed by 1 speed. (Upper limit 3rd speed)

3) Reset conditions

When either of the following conditions is satisfied.

- a) The outdoor air temperature (TH2) is 24°C or higher.
- b) The compressor command speed is 0 rps.

(ii) Heating

1) Operating conditions

When the outdoor air temperature (TH2) is 0°C or lower continues for 30 seconds while the compressor speed is other than 0 rps.

2) Detail of operation

The outdoor fan is stepped up by 2 speed step at each 20 seconds. (Upper limit 8th speed)

3) Reset conditions

When either of the following conditions is satisfied.

- a) The outdoor air temperature (TH2) is 2°C or higher.
- b) The compressor speed is 0 rps.

(r) Refrigeration cycle system protection

(i) Starting conditions

- 1) When 5 minutes have elapsed after the compressor ON or the completion of the defrost operation.
- 2) Other than the defrost operation.
- 3) When, after satisfying the conditions of 1) and 2) above, the compressor speed, indoor temperature (Th1) and indoor heat exchanger temperature (Th2) have satisfied the conditions in the following table for 5 minutes.

Operation mode	Compressor speed (N)	Indoor temperature (Th1)	Indoor temperature (Th1)/ Indoor heat exchanger temperature (Th2)
Cooling	50≦N	10≦Th1≦40	Th1-4 <th2< td=""></th2<>
Heating (1)	50≦N	0≤Th1≤40	Th2 <th1+6< td=""></th1+6<>

Note (1) Except that the fan speed is HI in heating operation.

(ii) Contents of control

- 1) When the conditions of (i) above are satisfied, the compressor stops.
- 2) Error stop occurs when the compressor has stopped 3 times within 60 minutes.

(iii) Reset condition

When the compressor has been turned OFF

10. MAINTENANCE DATA

(1) Cautions

- (a) If you are disassembling and checking an air-conditioner, be sure to turn off the power before beginning. When working on indoor units, let the unit sit for about 1 minute after turning off the power before you begin work. When working on an outdoor unit, there may be an electrical charge applied to the main circuit (electrolytic condenser), so begin work only after discharging this electrical charge (to DC10V or lower).
- (b) When taking out printed circuit boards, be sure to do so without exerting force on the circuit boards or package components.
- (c) When disconnecting and connecting connectors, take hold of the connector housing and do not pull on the lead wires.

(2) Items to check before troubleshooting

- (a) Have you thoroughly investigated the details of the trouble which the customer is complaining about?
- (b) Is the air-conditioner running? Is it displaying any self-diagnosis information?
- (c) Is a power source with the correct voltage connected?
- (d) Are the control lines connecting the indoor and outdoor units wired correctly and connected securely?
- (e) Is the outdoor unit's service valve open?


(3) Troubleshooting procedure (If the air-conditioner does not run at all)

If the air-conditioner does not run at all, diagnose the trouble using the following troubleshooting procedure. If the air-conditioner is running but breaks down, proceed to troubleshooting step (4).


Important

When all the following conditions are satisfied, we say that the air-conditioner will not run at all.

- (a) The RUN light does not light up.
- (b) The flaps do not open.
- (c) The indoor unit fan motors do not run.
- (d) The self-diagnosis display does not function.



(4) Troubleshooting procedure (If the air-conditioner runs)



Note (1) Even in cases where only intermittent stop data are generated, the air-conditioning system is normal. However, if the same protective operation recurs repeatedly (3 or more times), it will lead to customer complaints. Judge the conditions in comparison with the contents of the complaints.